

Network Video Recorder User's Manual

Model No. K-NL304K/G
K-NL308K/G

Table of Contents

1	Features and Specifications	1
1.1	Overview.....	1
1.2	Features.....	1
1.3	Specifications	2
2	Front Panel and Rear Panel	4
2.1	Front Panel	4
2.2	Rear Panel.....	6
2.3	Alarm Connection	8
2.3.1	Alarm Port	8
2.3.2	Alarm input port.....	8
2.3.3	Alarm input and output port.....	8
2.3.4	Alarm relay specifications.....	9
2.4	Bidirectional talk	9
2.4.1	Device-end to PC-end.....	9
2.4.2	PC-end to the device-end.....	10
2.5	Mouse Operation	11
2.6	Remote Controller Operation.....	12
3	Device Installation	14
3.1	Check Unpacked NVR	14
3.2	About Front Panel and Rear Panel	14
3.3	HDD Installation.....	14
3.4	Connection Sample	16
4	Local Basic Operation	17
4.1	Boot up and Shutdown	17
4.1.1	Boot up	17
4.1.2	Shutdown	17
4.2	Startup Wizard.....	17
4.3	Navigation Bar	21
4.3.1	Main Menu	21
4.3.2	Output Screen	21
4.3.3	Tour	21
4.3.4	PTZ	21
4.3.5	CAMERA.....	21
4.3.6	Search	21
4.3.7	Alarm Status	22
4.3.8	Channel Info	22
4.3.9	Remote Device.....	22
4.3.10	Network	22
4.3.11	HDD Manager.....	22
4.3.12	USB Manager.....	22
4.4	Remote Device	23
4.4.1	Remote Device Connection	23
4.4.2	Short-Cut Menu.....	24
4.4.3	IMAGE	24
4.4.4	CAM NAME	26

4.4.5	Upgrade.....	27
4.4.6	UPNP.....	28
4.4.7	Built-in Switch Setup	28
4.5	Preview.....	28
4.5.1	Preview.....	29
4.5.2	Preview control interface	29
4.5.3	Right Click Menu.....	31
4.5.4	Preview Display Effect Setup.....	31
4.5.4.1	GUI.....	31
4.5.4.2	Tour	32
4.6	PTZ.....	34
4.6.1	PTZ Settings.....	34
4.6.2	PTZ Control	35
4.6.2.1	PTZ Function Setup.....	37
4.6.2.2	Call PTZ Function	39
4.7	Record and Snapshot.....	40
4.7.1	ENCODE.....	40
4.7.1.1	ENCODE.....	40
4.7.1.2	Snapshot.....	41
4.7.1.3	Overlay.....	42
4.7.2	Schedule	43
4.7.2.1	Schedule Record	43
4.7.2.2	Schedule Snapshot.....	46
4.7.3	Motion detect record/snapshot	48
4.7.3.1	Motion detect record	48
4.7.3.2	Motion Detect Snapshot	51
4.7.4	Alarm Record/Snapshot.....	51
4.7.4.1	Alarm Record	51
4.7.4.2	Alarm Snapshot	52
4.7.5	Manual Record/Snapshot.....	53
4.7.5.1	Manual Record.....	53
4.7.5.2	Manual Snapshot.....	54
4.7.6	Holiday Record/Snapshot.....	54
4.7.6.1	Holiday Record	54
4.7.6.2	Holiday Snapshot.....	56
4.7.7	Other Record/Snapshot	56
4.8	Playback and Search	56
4.8.1	Real-time Playback.....	56
4.8.2	Search Interface.....	56
4.8.2.1	Smart Search	61
4.8.2.2	Accurate playback by time	61
4.8.2.3	Mark Playback	62
4.8.3	Picture Playback	63
4.9	Backup.....	64
4.9.1	File Backup	64
4.9.2	Import/Export.....	65

4.9.3	Backup Log	66
4.9.4	USB Device Auto Pop-up	67
4.10	Alarm	68
4.10.1	Detect Alarm	68
4.10.1.1	Motion Detect	68
4.10.1.2	Tampering	72
4.10.1.3	Video Loss	73
4.10.2	Alarm output	74
4.10.3	Alarm Setup	75
4.10.4	Abnormality	81
4.11	Network.....	82
4.11.1	Basic Setup.....	82
4.11.1.1	Connection	84
4.11.1.2	WIFI.....	85
4.11.1.3	3G	86
4.11.1.4	PPPoE.....	87
4.11.1.5	DDNS Setup	88
4.11.1.6	UPnP	90
4.11.1.7	IP Filter.....	91
4.11.1.8	Email	93
4.11.1.9	FTP	94
4.11.1.10	SNMP	96
4.11.1.11	Multicast.....	97
4.11.1.12	Alarm Center.....	99
4.11.1.13	Auto register	99
4.11.1.14	SWITCH.....	100
4.11.2	Network Test.....	101
4.11.2.1	Network Test	101
4.11.2.2	Network Load	102
4.12	HDD Setup	103
4.12.1	Format	103
4.12.2	HDD Information	104
4.12.3	Advanced	106
4.13	Basic Setups.....	109
4.13.1	Device Setup	109
4.13.2	Data and Time	110
4.13.3	Holiday.....	111
4.14	Device Maintenance and Manager	112
4.14.1	System Info.....	112
4.14.1.1	Version	112
4.14.1.2	BPS	113
4.14.1.3	Online User	113
4.14.1.4	Remote Device Information	114
4.14.1.5	Remote.....	115
4.14.1.5.1	Device Status	115
4.14.1.5.2	Firmware	116

4.14.2	Log	117
4.14.3	Account.....	118
4.14.3.1	Add/Modify Group.....	120
4.14.3.2	Add/Modify User	120
4.14.4	Update	121
4.14.5	Default	122
4.14.6	RS232.....	122
4.14.7	Auto Maintain.....	123
4.14.8	Logout /Shutdown/Restart	124
5	Web Operation	125
5.1	General Introduction	125
5.1.1	Preparation	125
5.1.2	Log in	126
5.2	LAN Mode.....	127
5.3	Real-time Monitor	129
5.4	PTZ.....	130
5.5	Image/Alarm-out	132
5.5.1	Image.....	132
5.5.2	Alarm output	132
5.6	Multi Preview	132
5.7	WAN Login.....	133
5.8	Setup	134
5.8.1	REMOTE	134
5.8.1.1	Remote Device	134
5.8.1.2	IMAGE.....	136
5.8.1.3	ENCODE	138
5.8.1.3.1	Encode	138
5.8.1.3.2	Snapshot	140
5.8.1.3.3	Video Overlay.....	140
5.8.1.3.4	Path	141
5.8.1.4	CAM NAME.....	142
5.8.2	Network	142
5.8.2.1	TCP/IP.....	142
5.8.2.2	Connection	143
5.8.2.3	WIFI.....	144
5.8.2.4	3G	144
5.8.2.4.1	CDMA/GPRS	144
5.8.2.4.2	Mobile.....	145
5.8.2.5	PPPoE.....	146
5.8.2.6	DDNS	146
5.8.2.7	IP filter	148
5.8.2.8	Email	148
5.8.2.9	FTP	150
5.8.2.10	UPnP.....	150
5.8.2.11	SNMP	151
5.8.2.12	Multicast.....	152
5.8.2.13	Register.....	152

5.8.2.14	Alarm Centre	153
5.8.3	Event.....	153
5.8.3.1	Detect.....	153
5.8.3.1.1	Motion Detect	153
5.8.3.1.2	Video Loss.....	157
5.8.3.1.3	Tampering	158
5.8.3.2	Alarm.....	158
5.8.3.2.1	Alarm	158
5.8.3.2.2	Net Alarm.....	160
5.8.3.2.3	IPC External Alarm.....	161
5.8.3.2.4	IPC Offline Alarm.....	161
5.8.3.3	Abnormality	162
5.8.4	Storage.....	164
5.8.4.1	Schedule	164
5.8.4.2	CTORAGE	166
5.8.4.2.1	Local Storage	166
5.8.4.2.2	HDD.....	167
5.8.4.3	Record Control	167
5.8.4.4	HDD MANAGER	168
5.8.4.4.1	Main Stream	168
5.8.4.4.2	Sub Stream	168
5.8.4.4.3	Snapshot	169
5.8.5	Setting.....	169
5.8.5.1	General	169
5.8.5.1.1	General.....	169
5.8.5.1.2	Date and time	170
5.8.5.1.3	Holiday Setup.....	170
5.8.5.2	Account	171
5.8.5.2.1	User name.....	171
5.8.5.2.2	Group	173
5.8.5.3	Display	175
5.8.5.3.1	Display.....	175
5.8.5.3.2	Tour	176
5.8.5.4	Alarm Out.....	177
5.8.5.5	Default.....	177
5.8.5.6	Import/Export	177
5.8.5.7	Auto maintain	178
5.8.5.8	Upgrade	178
5.8.5.9	RS232	178
5.8.5.10	PAN/TILT/ZOOM.....	179
5.9	Information.....	180
5.9.1	Version.....	180
5.9.2	Log	181
5.9.3	Online User.....	181
5.10	Playback	182
5.11	Alarm	186

5.12	Log out.....	187
5.13	Un-install Web Control.....	188
6	Glossary.....	189
7	Appendix A HDD Capacity Calculation	190

Welcome

Thank you for purchasing our network video recorder!

This user's manual is designed to be a reference tool for your system.

Please open the accessory bag to check the items one by one in accordance with the list below.

Important Safeguards and Warnings

1 . Electrical safety

All installation and operation here should conform to your local electrical safety codes.

The product must be grounded to reduce the risk of electric shock.

We assume no liability or responsibility for all the fires or electric shock caused by improper handling or installation.

2 . Transportation security

Heavy stress, violent vibration or water splash are not allowed during transportation, storage and installation.

3 . Installation

Keep upwards. Handle with care.

Do not apply power to the NVR before completing installation.

Do not place objects on the NVR

4 . Qualified engineers needed

All the examination and repair work should be done by the qualified service engineers.

We are not liable for any problems caused by unauthorized modifications or attempted repair.

5 . Environment

The NVR should be installed in a cool, dry place away from direct sunlight, inflammable, explosive substances and etc.

This series product shall be transported, storage and used in the specified environments.

6. Accessories

Be sure to use all the accessories recommended by manufacturer.

Before installation, please open the package and check all the components are included.

7. Lithium battery

Improper battery use may result in fire, explosion, or personal injury!

When replace the battery, please make sure you are using the same model!

Before your operation please read the following instructions carefully.

● Installation environment

- ✧ Keep away from extreme hot places and sources;
- ✧ Avoid direct sunlight;
- ✧ Keep away from extreme humid places;
- ✧ Avoid violent vibration;
- ✧ Do not put other devices on the top of the NVR;
- ✧ Be installed in well ventilated place; do not block the vent.

1 Features and Specifications

1.1 Overview

This series NVR is a high performance network video recorder. This series product support local preview, multiple-window display, recorded file local storage, remote control and mouse shortcut menu operation, and remote management and control function.

This series product supports centre storage, front-end storage and client-end storage. The monitor zone in the front-end can be set in anywhere. Working with other front-end devices such as IPC, NVS, this series product can establish a strong surveillance network via the CMS. In the network system, there is only one network cable from the monitor centre to the monitor zone in the whole network. There is no audio/video cable from the monitor centre to the monitor zone. The whole project is featuring of simple connection, low-cost, low maintenance work.

This series NVR can be widely used in many areas such as public security, water conservancy, transportation and education.

1.2 Features

Real-time Surveillance	<ul style="list-style-type: none">• VGA, HDMI port. Connect to monitor to realize real-time surveillance. Some series support TV/VGA/HDMI output at the same time.• Short-cut menu when preview.• Support popular PTZ decoder control protocols. Support preset, tour and pattern.
Playback	<ul style="list-style-type: none">• Support each channel real-time record independently, and at the same time it can support search, forward play, network monitor, record search, download and etc.• Support various playback modes: slow play, fast play, backward play and frame by frame play.• Support time title overlay so that you can view event accurate occurred time• Support specified zone enlargement.
User Management	<ul style="list-style-type: none">• Each group has different management powers that can be edited freely. Every user belongs to an exclusive group.
Storage	<ul style="list-style-type: none">• Via corresponding setup (such as alarm setup and schedule setup), you can backup related audio/video data in the network video recorder.• Support Web record and record local video and storage the file in the client end.
Alarm	<ul style="list-style-type: none">• Respond to external alarm simultaneously (within 200MS), based on user's pre-defined relay setup, system can process the alarm input correctly and prompt user by screen and voice (support pre-recorded audio).• Support central alarm server setup, so that alarm information can remotely notify user automatically. Alarm input can be derived from various connected peripheral devices.• Alert you via email/sms.

Network Monitor	<ul style="list-style-type: none"> Through network, sending audio/video data compressed by IPC or NVS to client-ends, then the data will be decompressed and display. Support max 128 connections at the same time. Transmit audio/video data by HTTP, TCP, UDP, MULTICAST, RTP/RTCP and etc. Transmit some alarm data or alarm info by SNMP. Support WEB access in WAN/LAN.
Window Split	<ul style="list-style-type: none"> Adopt the video compression and digital process to show several windows in one monitor. Support 1/4/8/9-window display when preview and 1/4/9-window display when playback.
Record	<ul style="list-style-type: none"> Support normal/motion detect/alarm record function. Save the recorded files in the HDD, USB device, client-end PC, or network storage server. You can search or playback the saved files at the local-end or via the Web/USB device.
Backup	<ul style="list-style-type: none"> Support network backup, USB2.0 record backup function, the recorded files can be saved in network storage server, peripheral USB2.0 device, burner and etc.
Network Management	<ul style="list-style-type: none"> Supervise NVR configuration and control power via Ethernet. Support management via WEB.
Peripheral Equipment Management	<ul style="list-style-type: none"> Support peripheral equipment management such as protocol setup and port connection. Support transparent data transmission such as RS232 (RS-422), RS485 (RS-485).
Auxiliary	<ul style="list-style-type: none"> Support switch between NTSC and PAL. Support real-time system resources information and running statistics display. Support log file. Local GUI output. Shortcut menu operation via mouse. IR control function (For some series product only). Shortcut menu operation via remote control. Support IPC or NVS remote video preview and control.

1.3 Specifications

Parameter	Specifications	
	K-NL304K/G	K-NL308K/G
System Resources	4/8-channel series product support 4/8-channel HD connection respectively. Max supports 160Mbps.	
Operation System	Embedded Linux real-time operation system	
Operation Interface	WEB/Local GUI	
Video Compression	H.264/MJPEG	
Decode Capacity	Max supports 8-channel 720P, or 4-channel 1080P, or 4*3M or 2*5M decode.	
Audio Compression	G.711a	
Video Output	1-channel VGA analog video output.	
Video Input	4-ch network compression video input (Only E-Series camera)	8-ch network compression video input (Only E-Series camera)
HDMI	1-ch HDMI output.	

Audio Input	1-ch bidirectional talk input	
Audio Output	1-ch bidirectional talk output	
Window Split	1/4-window	1/4/8/9-window
Multiple-channel Playback	Max 4-channel 720P / 4-channel 1080P playback.	Max 8-channel 720P / 4-channel 1080P playback.
Alarm Input	4-ch alarm input	
Alarm Output	2-ch alarm output	
Storage	2 built-in SATA ports.	
RS232 Port	One RS232 port to debug transparent COM data.	
RS485 port	One RS485 port to control PTZ. Support various protocols.	
USB2.0 Port	2 peripheral USB ports. One USB2.0 port at the front panel and one USB3.0 port at the rear panel.	
Network Connection	One RJ45 10/100/1000Mbps self-adaptive Ethernet port.	
Power Port	Two power ports. Input DC12V/DC 48V.	One power ports. Input 100-240V, 47~63Hz.
Power Button	One button. At the rear panel.	
Power On-off Button	One button. At the front-panel.	
IR Receiver Window	Support IR remote control	
Clock	Built-in clock.	
Indication Light	One power status indicator light. One network status indicator light. One HDD status indicator light.	
Power Consumption	< 30W(Exclude HDD)	
Working Temperature	-10°C - +55°C	
Working Humidity	10% - 90%	
Air pressure	86kpa—106kpa	
Dimension	375 mm(W) × 278 mm(D) × 52 mm(H)	375 mm(W) × 323 mm(D) × 52 mm(H)
Weight	1.5~2.5kg (Exclude HDD)	
Installation	Desk installation	

Note

- EMS & Mobile-EMS do not support i-PRO series NVR
- Panasonic Security Viewer is not supported
- Bit rate: Suggested to set bit rate for E-Series camera to 2 Mbps or less
- Suggested to synchronize to external NTP server
- Suggested E-Series setting
 - Auto Reboot (once a week)
 - No overlapping scheduled REC & VMD REC
- See support web page below for further details
<http://security.panasonic.com/>*****

2 Front Panel and Rear Panel

2.1 Front Panel

The front panel is shown as below. See Figure 2-1.





Figure 2-1

Please refer to the following sheet for front panel button information.

Name	Icon	Function
Power button		Power button, press this button for three seconds to boot up or shut down NVR.
Shift	Shift	In textbox, click this button to switch between numeral, English(Small/Capitalized),donation and etc.
Up/1 Down/4		Activate current control, modify setup, and then move up and down.
		Increase/decrease numeral
		Assistant function such as PTZ menu.
		In text mode, input number 1/4 (English character G/H/I)
Left/2 Right/3		Shift current activated control,
		When playback, click these buttons to control playback bar. In text mode, input number 2(English character A/B/C) /3(English character D/E/F).
ESC	ESC	Go to previous menu, or cancel current operation.
		When playback, click it to restore real-time monitor mode.
Enter	ENTER	Confirm current operation
		Go to default button
		Go to menu
Record	REC	Manually stop/start recording, working with direction keys or numeral keys to select the recording channel.
Slow play/8		Multiple slow play speeds or normal playback. In text mode, input number 8 (English character T/U/V).

Assistant	Fn	One-window monitor mode, click this button to display assistant function: PTZ control and image color.
		Backspace function: in numeral control or text control, press it for 1.5seconds to delete the previous character before the cursor.
		In motion detection setup, working with Fn and direction keys to realize setup.
		In text mode, click it to switch between numeral, English character(small/capitalized) and etc.
		Realize other special functions.
Fast play/7	▶▶	Various fast speeds and normal playback. In text mode, input number 7 (English character P/Q/R/S).
Play previous/0	◀	In playback mode, playback the previous video In text mode, input number 0.
Reverse/Pause/6	◀	In normal playback or pause mode, click this button to reverse playback In reverse playback, click this button to pause playback. In text mode, input number 6 (English character M/N/O)
Play Next/9	▶	In playback mode, playback the next video In menu setup, go to down ward of the dropdown list. In text mode, input number 9 (English character W/X/Y/Z).
Play/Pause /5	▶	In normal playback click this button to pause playback In pause mode, click this button to resume playback. In text mode, input number 5(English character J/K/L).
USB port		To connect USB storage device, USB mouse.
Network abnormal indication light	Net	Network error occurs or there is no network connection, the light becomes red to alert you.
HDD abnormal indication light	HDD	HDD error occurs or HDD capacity is below specified threshold value, the light becomes red to alert you.
Record light	1-16	System is recording or not. It becomes on when system is recording.
IR Receiver	IR	It is to receive the signal from the remote control.

2.2 Rear Panel

The K-NL304K/G rear panel is shown as below. See Figure 2-2.




Figure 2-2

The K-NL308K/G rear panel is shown as below. See Figure 2-3.







Figure 2-3

Please refer to the following sheet for detailed information.

Name		Function
Power switch	-	Power ON/OFF button.
Power input socket	-	Input AC 100~240V. For K-NL308K/G product only.
DC 12V	Power input port	Input DC 12V/4A. For K-NL304K/G series product only.
DC 48V	Power input port	Switch power port. Input DC 48/1A. For K-NL304K/G product only.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as mike phone, pickup.
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. <ul style="list-style-type: none"> ● Bidirectional talk output. ● Audio output on 1-window video monitor. ● Audio output on 1-window video playback.
1~4	Alarm input port 1~4	<ul style="list-style-type: none"> ● There are two types; NO (normal open)/NC (normal close). ● When your alarm input device is using external power, please make sure the device and the NVR have the same ground.

N1, N2	Alarm output port 1~2	<ul style="list-style-type: none"> 2 groups of alarm output ports. (Group 1: port N1 ~ C1, Group 2: port N2 ~ C2). Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. N: Normal open alarm output port. C: Alarm output public end.
C1, C2		
A	RS-485 communication port	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
B		RS485_B. It is the cable B. You can connect to the control devices such as speed dome PTZ.
	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
	 USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS-232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	-	Built-in Switch. Support PoE. The 4 PoE series product supports total 48V 50W. The 8 PoE series product supports total 48V 120W. One PoE port max supports 15W.

2.3 Alarm Connection

2.3.1 Alarm Port

The alarm port is shown as below. See Figure 2-4




Figure 2-4

Icon	Function
1~4	ALARM1~ALARM4. The alarm becomes activated in the low level.
N1,N2,C1,C2	Two N activation output groups. (On-off button)
	GND
A/B	485 communication port. They are used to control devices such as PTZ. Please parallel connect 120TΩ between A/B cables if there are too many PTZ decoders.

Note

- Different models support different alarm input ports. Please refer to the specifications sheet for detailed information.
- Slight difference may be found on the alarm port layout.

2.3.2 Alarm input port

Connect the positive end (+) of the alarm input device to the alarm input port (ALARM IN 1~4) of the NVR. Connect the negative end (-) of the alarm input device to the ground end () of the NVR.

Note

- When connect the ground port of the alarm device to the NVR, you can use any of the GND ports () .
- Connect the C port of the alarm device to the alarm input port (ALARM) of the NVR.
- When there is peripheral power supplying for the alarm device, please make sure it is earthed with the NVR.

2.3.3 Alarm input and output port

- There is peripheral power supplying for the external alarm device.
- In case overload may result in NVR damage, please refer to the following relay specifications for

detailed information.

- A/B cable of the RS485 is for the A/B cable connection of the speed PTZ.

2.3.4 Alarm relay specifications

Model:	JRC-27F	
Material of the touch	Silver	
Rating (Resistance Load)	Rated switch capacity	30VDC 2A, 125VAC 1A
	Maximum switch power	125VA 160W
	Maximum switch voltage	250VAC, 220VDC
	Maximum switch current	1A
Insulation	Between touches with same polarity	1000VAC 1minute
	Between touches with different polarity	1000VAC 1minute
	Between touch and winding	1000VAC 1minute
Surge voltage	Between touches with same polarity	1500V (10×160us)
Length of open time	3ms max	
Length of close time	3ms max	
Longevity	Mechanical	50×10 ⁶ MIN (3Hz)
	Electrical	200×10 ³ MIN (0.5Hz)
Temperature	-40℃ - +70℃	

2.4 Bidirectional talk

2.4.1 Device-end to PC-end

Device Connection

Please connect the speaker or the pickup to the first audio input port in the device rear panel. Then connect the earphone or the sound box to the audio output port in the PC.

Login the Web and then enable the corresponding channel real-time monitor.

Please refer to the following interface to enable bidirectional talk. See Figure2-5.




Figure 2-5

Listening Operation

At the device end, speak via the speaker or the pickup, and then you can get the audio from the earphone or sound box at the pc-end. See Figure 2-6.




Figure 2-6

2.4.2 PC-end to the device-end

Device Connection

Connect the speaker or the pickup to the audio output port in the PC and then connect the earphone or the sound box to the first audio input port in the device rear panel.

Login the Web and then enable the corresponding channel real-time monitor.

Please refer to the above interface (Figure 2-6) to enable bidirectional talk.

Listening Operation

At the PC-end, speak via the speaker or the pickup, and then you can get the audio from the earphone or sound box at the device-end. See Figure 2-7.





Figure 2-7

2.5 Mouse Operation

Please refer to the following sheet for mouse operation instruction.

Left mouse click	When you have selected one menu item, left click mouse to view menu content.
	Modify checkbox or motion detection status.
	Click combo box to pop up dropdown list
	<p>In input box, you can select input methods. Left click the corresponding button on the panel you can input numeral/English character (small/capitalized). Here ← stands for backspace button. _ stands for space button.</p> <p>In English input mode: _stands for input a backspace icon and ← stands for deleting the previous character.</p>  <p>The image shows two keyboard layouts. The top layout is for English input mode, and the bottom layout is for numeral input mode. Both layouts show a standard QWERTY keyboard with additional function keys for backspace, space, and deleting.</p>
Double left click mouse	Implement special control operation such as double click one item in the file list to playback the video.
	<p>In multiple-window mode, double left click one channel to view in full-window.</p> <p>Double left click current video again to go back to previous multiple-window mode.</p>
Right mouse click	In real-time monitor mode, pops up shortcut menu.
	Exit current menu without saving the modification.
Press middle button	In numeral input box: Increase or decrease numeral value.
	Switch the items in the check box.
	Page up or page down
Move mouse	Select current control or move control
Drag mouse	Select motion detection zone
	Select privacy mask zone.

2.6 Remote Controller Operation




Figure 2-8

Number	Name	Function
1	Power button	Click it to boot up or shut down the device.
2	Address	Click it to input device number, so that you can control it.
3	Forward	Various forward speeds and normal speed playback.
4	Slow play	Multiple slow play speeds or normal playback.
5	Next record	In playback mode, playback the next video.
6	Previous record	In playback mode, playback the previous video.
7	Play/Pause	In pause mode, click this button to realize normal playback.
		In normal playback click this button to pause playback.
		In real-time monitor mode, click this button to enter video search menu.
8	Reverse/pause	Reverse playback pause mode, click this button to realize normal playback.
		In reverse playback click this button to pause playback.
9	Esc.	Go back to previous menu or cancel current operation (close upper interface or control)
10	Record	Start or stop record manually. In record interface, working with the direction buttons to select the record channel. Click this button for at least 1.5 seconds, system can go to the Manual Record interface.
11	Direction keys	Switch current activated control, go to left or right. In playback mode, it is to control the playback process bar. Aux function(such as switch the PTZ menu)

12	Enter /menu key	go to default button. go to the menu
13	Multiple-window switch	Switch between multiple-window and one-window.
14	Fn	In 1-ch monitor mode: pop up assistant function : PTZ control and Video color.
		Switch the PTZ control menu in PTZ control interface.
		In motion detection interface, working with direction keys to complete setup.
		In text mode, click it to delete character.
15	0-9 number key	Input password, channel or switch channel.
		Shift is the button to switch the input method.

3 Device Installation

Note: All the installation and operations here should conform to your local electric safety rules.

3.1 Check Unpacked NVR

When you receive the NVR from the forwarding agent, please check whether there is any visible damage. The protective materials used for the package of the NVR can protect most accidental clashes during transportation. Then you can open the box to check the accessories.

Please check the items in accordance with the list. Finally you can remove the protective film of the NVR.

3.2 About Front Panel and Rear Panel

The model label in the front panel is very important; please check according to your purchase order.

The label in the rear panel is very important too. Usually we need you to represent the serial number when we provide the service after sales.

3.3 HDD Installation

Important:

Please turn off the power before you replace the HDD.

The pictures listed below for reference only.

For the first time install, please be aware that whether the HDDs have been installed.

You can refer to the Appendix for recommended HDD brand. Please use HDD of 7200rpm or higher.

Usually we do not recommend the PC HDD.

Please follow the instructions below to install hard disk.



1. Loosen the screws of the upper cover and side panel.



2. Fix four screws in the HDD (Turn just three rounds).



3. Place the HDD in accordance with the four holes in the bottom.



4. Turn the device upside down and then turn the screws in firmly.

5. Fix the HDD firmly.

6. Connect the HDD cable and power cable.

Note: Be careful so that the cables are not in contact with the edge of the HDD.



7. Put the cover in accordance with the clip and then place the upper cover back.

8. Secure the screws in the rear panel and the side panel.

3.4 Connection Sample

Please refer to Figure 3-1 for connection sample.

The following figure is based on our K-NL308K/G product.




Figure 3-1

4 Local Basic Operation

4.1 Boot up and Shutdown

4.1.1 Boot up

Before the boot up, please make sure:

- The rated input voltage matches the device. Please make sure the power wire connection is OK. Then click the power on-off button.
- Always use the stable current, if necessary UPS is a best alternative measure.

Please follow the steps listed below to boot up the device.

- Connect the device to the monitor and then connect a mouse.
- Connect power cable.
- Click the power button at the front or rear panel and then boot up the device. After device booted up, the system is in multiple-channel display mode by default.

4.1.2 Shutdown

Note

- When you see corresponding dialogue box "System is shutting down..." Do not click power on-off button directly.
- Do not unplug the power cable or click power on-off button to shutdown device directly when device is running (especially when it is recording.)

There are three ways for you to log out.

- a) Main menu (**RECOMMENDED**)

From Main Menu->SHUTDOWN, select shutdown from dropdown list.

Click OK button, you can see device shuts down.

- b) From power on-off button on the front panel or remote control

Press the power on-off button on the NVR front panel or remote control for more than 3 seconds to shutdown the device.

- c) From power on-off button on the rear panel.

4.2 Startup Wizard

After device successfully booted up, it goes to startup wizard.

Click Cancel/Next button, you can see system goes to login interface.

Tips

Check the box Startup button here, system goes to startup wizard again when it boots up the next time.

Cancel the Startup button, system goes to the login interface directly when it boots up the next time.



Figure 4-1

Click Cancel button or Next Step button, system goes to login interface. See Figure 4-2.

- **Username:** ADMIN. **Password:** 12345. (Default)



Figure 4-2

Note:

For security reason, please modify password after you first login.

Within 30 minutes, three times login failure will result in system alarm and five times login failure will result in account lock!

Click OK button, you can go to General interface. See Figure 4-3.

For detailed information, please refer to chapter 4.13.1.

GENERAL

General Date&Time Holiday

Device Name: NVR

Device No.: 8

Language: ENGLISH

Video Standard: PAL

HDD Full: Overwrite

Pack Duration: 60 Minute

Realtime Play: 5 Minute

Auto Logout: 10 Minute

IPC Time Sync: 24 Hours

☐ Navigation Bar

Mouse Sensitivity: Slow ————— Fast

Default Apply

Back Next Cancel

Figure 4-3

Click Next button, you can go to network interface. See Figure 4-4.
For detailed information, please refer to chapter 4.11.

NETWORK

MTU: 1500

☐ LAN Download

IP Version: IPv4

MAC Address: 90:02:A9:B9:5D:FD

IP Address: 192 . 168 . 1 . 250 ☐ DHCP

Subnet Mask: 255 . 255 . 255 . 0

Default Gateway: 192 . 168 . 1 . 1

Preferred DNS: 8 . 8 . 8 . 8

Alternate DNS: 8 . 8 . 4 . 4

Default Back Next Cancel

Figure 4-4

Click Next button, you can go to remote device interface. See Figure 4-5

For detailed information, please refer to chapter 4.4.




Figure 4-5

Click Next button, you can go to Schedule interface. See Figure 4-6.

For detailed information, please refer to chapter 4.7.2.




Figure 4-6

Click Finish button, system pops up a dialogue box. Click the OK button, the startup wizard is complete. See Figure 4-7.



Figure 4-7

4.3 Navigation Bar


You need to go to the Main menu->SETTING->SYSTEM->GENERAL to enable navigation bar function; otherwise you cannot see the following interface.

The navigation bar is shown as below. See Figure 4-8.



Figure 4-8

4.3.1 Main Menu

Click button  to go to the main menu interface.


4.3.2 Output Screen

Select corresponding window-split mode and output channels.


4.3.3 Tour

Click button  to enable tour, the icon becomes , you can see the tour is in process.


4.3.4 PTZ

Click , system goes to the PTZ control interface. Please refer to chapter 4.6.2.

4.3.5 CAMERA


Click button , system goes to the color interface. Please refer to chapter 4.4.3.
Please make sure system is in one-channel mode.

4.3.6 Search

Click button , system goes to search interface. Please refer to chapter 4.8.2


4.3.7 Alarm Status



Click button , system goes to alarm status interface. It is to view device status and channel status. Please refer to chapter 4.14.1.4.

4.3.8 Channel Info



Click button , system goes to the channel information setup interface. It is to view information of the corresponding channel. See Figure 4-9.



Channel	Status	IP Address	Video Detect	IPC External Alarm	Camera Name
1		192.168.0.113	--	--	Channel 1
2		192.168.0.187	--	--	Channel 2
3		192.168.0.130	--	--	Channel 3
4		192.168.0.132	--	--	Channel 4
5		192.168.100.171	--	--	Channel 5
6		192.168.0.79	--	--	Channel 6
7		192.168.100.66	--	--	Channel 7
8		192.168.100.65	--	--	Channel 8

Refresh

Figure 4-9


4.3.9 Remote Device



Click , system goes to the remote device interface. Please refer to chapter 4.4


4.3.10 Network



Click , system goes to the network interface. It is to set network IP address, default gateway and etc. Please refer to chapter 4.11.


4.3.11 HDD Manager



Click , system goes to the HDD manager interface. It is to view and manage HDD information. Please refer to chapter 4.12.1.

4.3.12 USB Manager



Click , system goes to the USB Manager interface. It is to view USB information, backup and update. Please refer to chapter 4.9.1 file backup, chapter 4.9.3 backup log, chapter 4.9.2 import/export, and chapter 4.14.4 upgrade for detailed information.

4.4 Remote Device

4.4.1 Remote Device Connection

From Main menu->SETTING->REMOTE device or right click mouse on the preview interface and then select remote device item, you can see the following interface. See Figure 4-10.



Figure 4-10

Click Device search button, you can view the searched IP addresses at the top pane of the interface. Double click an IP address or check one IP address and then click Add button, you can add current device to the bottom pane of the interface. System supports batch add function.

Click Manual Add button, you can add a device directly. Here you can set TCP/UDP/auto connection mode. The default setup is TCP. See Figure 4-11.

Important

Please note the manual add function is for Private, Panasonic, Sony, Dynacolor, Samsung, AXIS, Arecont, ONVIF and Custom. When the type is the custom, you can just input URL address, user name and password connect to the network camera without considering network camera manufacturer. Please contact your network camera manufacturer for the URL address.



The image shows a 'Manual Add' configuration window with a dark blue background. At the top, there is a title bar with a 'Manual Add' button. Below the title bar, there are several configuration fields: 'Channel' (dropdown menu showing '8'), 'Manufacturer' (dropdown menu showing 'Panasonic'), 'IP Address' (text field showing '192.168.0.0'), 'RTSP Port' (text field showing '554'), 'HTTP Port' (text field showing '80'), 'User Name' (text field showing 'admin'), 'Password' (password field with five dots), 'Decode Buffer' (dropdown menu showing 'Default'), and 'Remote Channel No.' (text field showing '1'). At the bottom, there are three radio buttons: 'Auto' (selected), 'TCP', and 'UDP'. At the very bottom, there are 'Save' and 'Cancel' buttons.

Figure 4-11

4.4.2 Short-Cut Menu

In the preview interface, for the channel of no IPC connection, you can click the icon “+” in the centre of the interface to quickly go to the Remote Device interface. See Figure 4-12.




Figure 4-12

4.4.3 IMAGE

From Main Menu->SETTING->REMOTE->IMAGE, you can see the camera interface is shown as below. See Figure 4-13.

- Channel: Select a channel from the dropdown list.
- Saturation: It is to adjust monitor window saturation. The value ranges from 0 to 100. The default value is 50. The larger the number, the stronger the color is. This value has no effect on the general brightness of the whole video. The video color may become too strong if the value is too high. For

the grey part of the video, the distortion may occur if the white balance is not accurate. Please note the video may not be attractive if the value is too low. The recommended value ranges from 40 to 60.

- **Brightness:** It is to adjust monitor window bright. The value ranges from 0 to 100. The default value is 50. The larger the number is, the brighter the video is. When you input the value here, the bright section and the dark section of the video will be adjusted accordingly. You can use this function when the whole video is too dark or too bright. Please note the video may become hazy if the value is too high. The recommended value ranges from 40 to 60.
- **Contrast:** It is to adjust monitor window contrast. The value ranges from 0 to 100. The default value is 50. The larger the number is, the higher the contrast is. You can use this function when the whole video bright is OK but the contrast is not proper. Please note the video may become hazy if the value is too low. If this value is too high, the dark section may lack brightness while the bright section may over exposure. The recommended value ranges from 40 to 60.
- **Auto Iris:** It is for the device of the auto lens. You can check the box before ON to enable this function. The auto iris may change if the light becomes different. When you disable this function, the iris is at the max. System does not add the auto iris function in the exposure control. This function is on by default.
- **Sharpness:** The value here is to adjust the edge of the video. The value ranges from 0 to 100. The larger the value is, the clear the edge is and vice versa. Please note there is noise if the value here is too high. The default value is 50 and the recommended value ranges from 40 to 60.
- **Mirror:** It is to switch video up and bottom limit. This function is disabled by default.
- **Flip:** It is to switch video left and right limit. This function is disabled by default.
- **BLC:** It includes several options: BLC/WDR/HLC/OFF.
- ✧ **BLC:** The device auto exposures according to the environments situation so that the darkest area of the video is cleared
- ✧ **WDR:** For the WDR scene, this function can lower the high bright section and enhance the brightness of the low bright section. So that you can view these two sections clearly at the same time. The value ranges from 1 to 100. When you switch the camera from no-WDR mode to the WDR mode, system may lose several seconds record video.
- ✧ **HLC:** After you enabled HLC function, the device can lower the brightness of the brightest section according to the HLC control level. It can reduce the area of the halo and lower the brightness of the whole video.
- ✧ **OFF:** It is to disable the BLC function. Please note this function is disabled by default.
- **Scene Mode:** It is to set the white balance mode. It has effect on the general hue of the video. This function is on by default. You can select the different scene mode such as auto, sunny, cloudy, home, office, night, disable and etc to adjust the video to the best quality.
- ✧ **Auto:** The auto white balance is on. System can auto compensate the color temperature to make sure the video color is proper.
- ✧ **Sunny:** The threshold of the white balance is in the sunny mode.
- ✧ **Night:** The threshold of the white balance is in the night mode.
- ✧ **Customized:** You can set the gain of the red/blue channel. The value ranges from 0 to 100.
- **Day&night.** It is to set device color and the B/W mode switch. The default setup is auto.
- ✧ **Colorfull:** Device outputs the color video.
- ✧ **Auto:** Device auto select to output the color or the B/W video according to the device feature (The general bright of the video or there is IR light or not.)
- ✧ **B/W:** The device outputs the black and white video.

✧ Sensor: It is to set when there is peripheral connected IR light.
Please note some non-IR series product support sensor input function.



Figure 4-13

4.4.4 CAM NAME

From Main Menu->SETTING->REMOTE->CAM NAME, you can see an interface shown as in Figure 4-14.

It is to modify channel name. It max supports 31-character.

Please note you can only modify the channel name of the connected network camera.



Figure 4-14

4.4.5 Upgrade

It is to update the network camera.

From Main menu->SETTING->REMOTE->REMOTE, the interface is shown as below. See Figure 4-15.

Click Browse button and then select the upgrade file. Then select a channel (or you can select device type filter to select several devices at the same time.)

Click Begin button to upgrade. You can see the corresponding dialogue once the upgrade is finish.




Figure 4-15

4.4.6 UPNP

Important

Do not connect the switch to the PoE port, otherwise the connection may fail!

Please connect the IPC to the PoE port of the device rear panel (Figure 4-16), system can auto connect to the network camera. Please note the following figure is for reference only.




Figure 4-16

4.4.7 Built-in Switch Setup

The built-in switch function is for product of PoE port.

From Main menu->SETTING->NETWORK->SWITCH, you can set switch IP address, subnet mask, gateway and etc. See Figure 4-17.



Figure 4-17

4.5 Preview

After device booted up, the system is in multiple-channel display mode. See Figure 4-18. Please note the

displayed window amount may vary. The following figure is for reference only. Please refer to chapter 1.3 Specifications for the window-amount your product supported.



Figure 4-18

4.5.1 Preview

If you want to change system date and time, you can refer to general settings (Main Menu->SETTING->SYSTEM->GENERAL). If you want to modify the channel name, please refer to the display settings (Main Menu->SETTING->REMOTE->CAM NAME)
Please refer to the following sheet for detailed information.

1		Recording status	3		Video loss
2		Motion detection	4		Camera lock

Tips

- Preview drag: If you want to change position of channel 1 and channel 2 when you are previewing, you can left click mouse in the channel 1 and then drag to channel 2, release mouse you can switch channel 1 and channel 2 positions.
- Use mouse middle button to control window split: You can use mouse middle button to switch window split amount.

4.5.2 Preview control interface

Move you mouse to the top centre of the video of current channel, you can see system pops up the preview control interface. See Figure 4-19. If your mouse stays in this area for more than 6 seconds and has no operation, the control bar automatically hides.




Figure 4-19 Digital Channel

1) Realtime playback



It is to playback the previous 5-60 minutes record of current channel.

Please go to the Main menu->SETTING->SYSTEM->GENERAL to set real-time playback time.

System may pop up a dialogue box if there is no such record in current channel.

2) Digital zoom

It is to zoom in specified zone of current channel. It supports zoom in function of multiple-channel.

Click button , the button is shown as .

There are two ways for you to zoom in.

- Drag the mouse to select a zone, you can view an interface show as Figure 4-20.



Figure 4-20

- Put the middle button at the centre of the zone you want to zoom in, and move the mouse, you can view an interface shown as in Figure 4-21.




Figure 4-21


Right click mouse to cancel zoom and go back to the original interface.

3) Manual record function

It is to backup the video of current channel to the USB device. System cannot backup the video of multiple-channel at the same time.



Click button , system begins recording. Click it again, system stops recording. You can find the record file on the flash disk.



4) Manual Snapshot

Click  to snapshot 1-5 times. The snapshot file is saved on the USB device or HDD. You can go to the Search interface (chapter 4.8) to view.

5) Bidirectional talk

If the connected front-end device supports bidirectional talk function, you can click this button. Click

button  to start bidirectional talk function the icon now is shown as . Now the rest bidirectional talk buttons of digital channel becomes null too.

Click  again, you can cancel bidirectional talk and the bidirectional talk buttons of other digital channels become as .

6) Remote device

Shortcut menu. Click it to go to the remote device interface to add/delete remote device or view its corresponding information. Please refer to chapter 4.4.2 for detailed information.

4.5.3 Right Click Menu

After you logged in the device, right click mouse, you can see the short cut menu. Please see Figure 4-22.

- Window split mode: You can select window amount and then select channels.
- PTZ: Click it to go to PTZ interface.
- Auto focus: It is to set auto focus function. Please make sure the connected network camera supports this function.
- IMAGE: Set video corresponding information.
- Search: Click it to go to Search interface to search and playback a record file.
- Record: Enable/disable record channel.
- Alarm output: It is to set alarm output mode. Generate alarm output signal manually.
- Remote device: Search and add a remote device.
- Main menu: Go to system main menu interface.

Tips:

Right click mouse to go back to the previous interface.



Figure 4-22

4.5.4 Preview Display Effect Setup

4.5.4.1 GUI

From Main Menu->SETTING->SYSTEM->DISPLAY, you can go to the following interface. See Figure 4-23.




Figure 4-23

Now you can set corresponding information.

- Resolution: There are four options: 1280×1024 (Default), 1280×720, 1920×1080, 1024×768. Please note the system needs to reboot to activate current setup.
- Transparency: Here is for you to adjust transparency. The value ranges from 0 to 100.
- Time display: You can select to display time or not when system is playback.
- Channel display: You can select to channel name or not when system is playback.
- Image enhance: Check the box; you can optimize the margin of the preview video.
- Original Scale: Check the box; you can see the original resolution of the preview video.

Click Save button to save current setup.

Note

The display parameter here has no effect on the record file and playback effect.

4.5.4.2 Tour

From Main menu->SETTING->SYSTEM->DISPLAY, you can see an interface shown as in Figure 4-24. Here you can set tour parameter.



- Enable tour: Check the box here to enable tour function.
- Interval: Input proper interval value here. The value ranges from 5-120 seconds.
- Monitor tour type: System support 1/8-window tour.
- Alarm tour type: System support 1/8-window tour.



Figure 4-24

Tips



On the navigation bar, click  /  to enable/disable tour.
Click Save button to save current setup.

4.6 PTZ

Note:

Before you control the PTZ, please make sure the PTZ decoder and the NVR network connection is OK and the corresponding settings are right.

4.6.1 PTZ Settings

Cable Connection

Please follow the procedures below to go on cable connection

- Connect the dome RS485 port to NVR RS485 port.
- Connect dome video output cable to NVR video input port.
- Connect power adapter to the dome.

In the main menu, from SETTING->SYSTEM->PAN/TILT/ZOOM, you can see an interface is shown as in Figure 4-25. Here you can set the following items:

- Channel: Select the current camera channel.
- PTZ type: There are two types: local/remote. Please select local mode if you are connect RS485 cable to connect to the Speed dome (PTZ). Please select remote mode if you are connecting to the network PTZ camera.
- Protocol: Select corresponding PTZ protocol(such as PELCOD)
- Address: Default address is 1.
- Baud rate: Select corresponding baud rate. Default value is 9600.
- Data bit: Select corresponding data bits. Default value is 8.
- Stop bit: Select corresponding stop bits. Default value is 1.
- Parity: There are three options: odd/even/none. Default setup is none.



Figure 4-25

If you are connecting to network PTZ, the PTZ type shall be remote. See Figure 4-26.



Figure 4-26

4.6.2 PTZ Control

After completing all the setting please click save button. Right click mouse (click “Fn” Button in the front panel or click “Fn” key in the remote control). The interface is shown as in Figure 4-27. Please note you can only go to the PTZ control interface when you are in 1-window display mode.



Figure 4-27



The PTZ setup is shown as in See Figure 4-28.

Please note the commend name is grey once device does not support this function.

The PTZ operation is only valid in one-window mode.

Here you can control PTZ direction, speed, zoom, focus, iris, preset, tour, scan, pattern aux function, light and wiper, rotation and etc.

Speed is to control PTZ movement speed. The value ranges from 1 to 8. The speed 8 is faster than speed 1. You can use the remote control to click the small keyboard to set.

You can click  and  of the zoom, focus and iris to zoom in/out, definition and brightness.

The PTZ rotation supports 8 directions. If you are using direction buttons on the front panel, there are only four directions: up/down/left/right.















Figure 4-28

In the middle of the eight direction arrows, there is a 3D intelligent positioning key. See Figure 4-29. Please make sure your protocol supports this function and you need to use mouse to control. Click this key, system goes back to the single screen mode. Drag the mouse in the screen to adjust section size. The dragged zone supports 4X to 16X speeds. It can realize PTZ automatically. The smaller zone you dragged, the higher the speed.



Figure 4-29

Name	Function key	function	Shortcut key	Function key	function	Shortcut key
Zoom		Near			Far	
Focus		Near			Far	
Iris		close			Open	


In Figure 4-28, click  to open the menu, you can set preset, tour, pattern, scan and etc. See Figure 4-30.













Figure 4-30

Please refer to the following sheet for detailed information.

Please note the above interface may vary due to different protocols. The button is grey and cannot be selected once the current function is null.

Right click mouse or click the ESC button at the front panel to go back to the Figure 4-28.

Icon	Function	Icon	Function
	Preset		Flip
	Tour		Reset
	Pattern		Aux
	Scan		Aux on-off button
	Rotate		Go to menu

4.6.2.1 PTZ Function Setup


Click , you can go to the following interface to set preset, tour, pattern, and scan. See Figure 4-31.



Figure 4-31

Preset Setup

In Figure 4-31, click preset button and use eight direction arrows to adjust camera to the proper position. The interface is shown as in Figure 4-32.

Click Set button and then input preset number.

Click Set button to save current preset.



Figure 4-32

Tour Setup

In Figure 4-31, click tour button.

Input tour value and preset No. Click Add preset button to add current preset to the tour. See Figure 4-33.

Tips

Repeat the above steps to add more presets to the tour. Click Del preset button to remove it from the tour. Please note some protocols do not support delete preset function.



Figure 4-33

Pattern Setup

In Figure 4-31, click Pattern button and input pattern number.

Click Begin button to start direction operation. Or you can go back to Figure 4-28 to operate zoom/focus/iris/direction operation.

In Figure 4-31, click End button.



Figure 4-34

Border Setup

In Figure 4-31, click Border button.

Use direction buttons to set camera left limit and then click Left button.



Use direction buttons to set camera right limit and then click Right button. Now the scan setup process is complete.





Figure 4-35

4.6.2.2 Call PTZ Function

Call Preset

In Figure 4-30, input preset value and then click  to call a preset. Click  again to stop call.



Call Pattern

In Figure 4-30, input pattern value and then click  to call a pattern. Click  again to stop call.


Call Tour

In Figure 4-30, input tour value and then click  to call a tour. Click again  to stop call.

Call Scan

In Figure 4-30, input autoscan value and then click  to call a tour. Click again  to stop call.


Autopan

In Figure 4-30, click  to enable the camera to rotate.
System supports preset, tour, pattern, scan, rotate, light and etc function.

Note:

- Preset, tour and pattern all need the value to be the control parameters. You can define it as you require.
- You need to refer to your camera user's manual for Aux definition. In some cases, it can be used for special process.

Aux

Click , system goes to the following interface. The options here are defined by the protocol. The aux number is corresponding to the aux on-off button of the decoder. See Figure 4-36.




Figure 4-36

4.7 Record and Snapshot

The record/snapshot priority is: ALARM->MOTION DETECT->SCHEDULE.

4.7.1 ENCODE

4.7.1.1 ENCODE

Encode setting is to set IPC encode mode, resolution, bit stream type and etc

From Main menu->SETTING->REMOTE->ENCODE, you can see the following interface. See Figure 4-37.

- Channel: Select the channel you want.
- Code-Stream Type: Please select from the dropdown list. There are some options: regular/motion detect/alarm. You can set the various encode parameters for different record types.
- Compression: System supports H.264, MPEG4, MJPEG and etc.
- Resolution: The mainstream resolution type is IPC's encoding config. Generally there is D1/720P/1080P.
- Frame rate: It ranges from 1fps to 25fps in NTSC mode and 1fps to 30fps in PAL mode.
- Bit rate type: System supports two types: CBR and VBR. In VBR mode, you can set video quality.
- Quality: There are six levels ranging from 1 to 6. The sixth level has the highest image quality.
- Bit Rate : You can select bitrate value in the combo box.
- Video/audio: You can enable or disable the video/audio. Please note, once you enable audio function for one channel, system may enable audio function of the rest channels by default.
- Copy: After you complete the setup, you can click Copy button to copy current setup to other channel(s). You can see an interface is shown as in Figure 4-39. You can see current channel number is grey. Please check the number to select the channel or you can check the box ALL. Please click the OK button in Figure 4-39 and Figure 4-38 respectively to complete the setup. Please note, once you check the All box, you set same encode setup for all channels. Audio/video enable box, overlay button and the copy button is shield.

Please highlight icon  to select the corresponding function.



Figure 4-37

4.7.1.2 Snapshot

Here you can set snapshot mode, picture size, quality and frequency. See Figure 4-38.

- Mode: There are two modes: timing and trigger. If you set timing mode, you need to set snapshot frequency. If you set trigger snapshot, you need to set snapshot activation operation.

- Image size: Here you can set snapshot picture size.
- Quality: Here you can set snapshot quality. The value ranges from 1 to 6.
- Snapshot Frequency: It is for you to set timing (schedule) snapshot interval.



Figure 4-38



Figure 4-39

4.7.1.3 Overlay

Click overlay button, you can see an interface is shown in Figure 4-40.

- Cover area: Here is for you to cover area section. You can drag you mouse to set proper section size. In one channel video, system max supports 4 zones in one channel. You can set with Fn button or direction buttons.
- Preview/monitor: The cover area has two types. Preview and Monitor. Preview means the privacy mask zone cannot be viewed by user when system is in preview status. Monitor means the privacy mask zone cannot be view by the user when system is in monitor status.

- Time display: You can select system displays time or not when you playback. Please click set button and then drag the title to the corresponding position in the screen.
- Channel display: You can select system displays channel number or not when you playback. Please click set button and then drag the title to the corresponding position in the screen.



Figure 4-40

4.7.2 Schedule




The record type priority is: Alarm>Motion detect>Regular.


4.7.2.1 Schedule Record

Set record time, record plan and etc. Please note system is in 24-hour record by default after its first boot up.

In the main menu, from Main menu->SETTING->STORAGE->SCHEDULE, you can go to schedule menu. See Figure 4-44. There are total six periods.


- Channel: Please select the channel number first. You can select “all” if you want to set for the whole channels.

✧ : Sync connection icon. Select icon  of several dates, all checked items can be edited or together. Now the icon is shown as .

✧ : Click it to delete a record type from one period.

- Record Type: Please check the box to select corresponding record type. There are four types: Regular/MD (motion detect)/Alarm/MD&Alarm.
- Week day: There are eight options: ranges from Saturday to Sunday and all.
- Holiday: It is to set holiday setup. Please note you need to go to the General interface (Main Menu->SETTING->SYSTEM->GENERAL) to add holiday first. Otherwise you cannot see this item.
- Pre-record: System can pre-record the video before the event occurs into the file. The value ranges from 1 to 30 seconds depending on the bit stream.
- Redundancy: System supports redundancy backup function. It allows you backup recorded file in two disks. You can highlight Redundancy button to activate this function. Please note, before enable this function, please set at least one HDD as redundant. (Main menu->SETTING->STORAGE->HDD MANAGER). **Please note this function is null if there is only one HDD.**
- ANR: It is to save video to the SD card of the network camera in case the network connection fails. The value ranges from 0s~43200s. After the network connection resumed, the system can get the video from the SD card and there is no risk of record loss.



- Period setup: Click button  after one date or a holiday, you can see an interface shown as in Figure 4-45. There are four record types: regular, motion detection (MD), Alarm, MD & alarm.

Please following the steps listed below to draw the period manually.

- Select a channel you want to set. See Figure 4-41.



Figure 4-41

- Set record type. See Figure 4-42.



Figure 4-42

- Please draw manually to set record period. There are six periods in one day. See Figure 4-43.



Figure 4-43

Please check the box ☐ to select the corresponding function. After completing all the setups please click save button, system goes back to the previous menu.

There are color bars for your reference. Green color stands for regular recording, yellow color stands for motion detection and red color stands for alarm recording. The blue means the MD and alarm record is valid. Once you have set to record when the MD and alarm occurs, system will not record neither motion detect occurs nor the alarm occurs.




Figure 4-44



Figure 4-45

Quick Setup

Copy function allows you to copy one channel setup to another. After setting in channel 1, click Copy button, you can go to interface Figure 4-46. You can see current channel name is grey such as channel 1. Now you can select the channel you want to paste such as channel 5/6/7. If you want to save current setup of channel 1 to all channels, you can click the first box "ALL". Click the OK button to save current copy setup. Click the OK button in the Encode interface, the copy function succeeded.

Please note, if you select ALL in Figure 4-46, the record setup of all channels are the same and the Copy button becomes hidden.



Figure 4-46

Click OK button to save current setup.

4.7.2.2 Schedule Snapshot

From Main menu->SETTING->STORAGE->RECORD or on the preview interface, right click mouse and then select record item, you can see Figure 4-47.

Select snapshot channel and enable snapshot function. Click Save button.




Figure 4-47

From Main menu->SETTING->REMOTE->ENCODE->Snapshot, you can go to snapshot interface. See Figure 4-48.

Select the snapshot channel from the dropdown list and then select snapshot mode as Timing (Schedule) from the dropdown list and then set picture size, quality and snapshot frequency.



Figure 4-48

In the main menu, from Main menu->SETTING->STORAGE->SCHEDULE, you can go to schedule menu. See Figure 4-44. Here you can set snapshot period. There are total six periods in one day. Please refer to chapter 4.7.2.1 for detailed setup information. The setup steps are general the same.



Figure 4-49

Note

- Please note the trigger snapshot has the higher priority than regular snapshot. If you have enabled these two types at the same time, system can activate the trigger snapshot when an alarm occurs, and otherwise system just operates the regular snapshot.
- Only the trigger snapshot supports this function. The regular snapshot function cannot send out picture via the email. But you can upload the picture to a FTP.

4.7.3 Motion detect record/snapshot

4.7.3.1 Motion detect record

- From Main menu->SETTING->EVENT->DETECT, you can go to the following interface. See Figure 4-50.



Figure 4-50

- b) Select motion detect from the event type dropdown list. Select a channel from the dropdown list and then check the enable button to enable motion detect function.
- c) Click Region Select button to set motion detect zone. There are 396(PAL)/330(NTSC) small zones. The green zone is current cursor position. Grey zone is the motion detection zone. Black zone is the disarmed zone. You can click Fn button to switch between the arm mode and disarm mode. In arm mode, you can click the direction buttons to move the green rectangle to set the motion detection zone. After you completed the setup, please click ENTER button to exit current setup. Do remember click save button to save current setup. If you click ESC button to exit the region setup interface system will not save your zone setup.
- d) Period: Click set button, you can see an interface is shown as in Figure 4-73. Here you can set motion detect period. System only enables motion detect operation in the specified periods. It is not for video loss or the tampering. There are two ways for you to set periods. Please note system only supports 6 periods in one day.
- e) Set sensitivity. Please note the sixth level has the highest sensitivity.
- f) Click Save button to complete motion detect setup.
- g) From Main menu->SETTING->STORAGE->SCHEDULE. See Figure 4-44
- h) Set motion detect record channel, period and the record type shall be motion detect (MD). Please refer to chapter 4.7.2.
- i) Click Copy button to copy current setup to other channel(s).
- j) Click OK button to complete motion detect record setup.

Setup

0 2 4 6 8 10 12 14 16 18 20 22 24

☐ All ☐ Sun ☐ Mon ☐ Tue ☐ Wed ☐ Thu ☐ Fri ☐ Sat

Setup Setup Setup Setup Setup Setup Setup

Default OK Cancel

Figure 4-51

Period

Current Date: Sun

Period 1 00 : 00 - 24 : 00 ☒

Period 2 00 : 00 - 24 : 00 ☐

Period 3 00 : 00 - 24 : 00 ☐

Period 4 00 : 00 - 24 : 00 ☐

Period 5 00 : 00 - 24 : 00 ☐

Period 6 00 : 00 - 24 : 00 ☐

Copy

☐ All ☒ Sun ☐ Mon ☐ Tue ☐ Wed ☐ Thu ☐ Fri ☐ Sat

Save

Figure 4-52

4.7.3.2 Motion Detect Snapshot

- From Main menu->SETTING->REMOTE->ENCODE->Snapshot, you can go to snapshot interface. See Figure 4-53.
- In Figure 4-53, select trigger snapshot from the dropdown list and then set picture size, quality and snapshot frequency. Click OK button to save current setup.
- From Main menu->SETTING->EVENT->DETECT, here you can select motion detect type, motion detect channel and then check the enable box. Please refer to chapter 4.7.3.1.
- Click OK button to complete motion detect setup.



Figure 4-53

4.7.4 Alarm Record/Snapshot

4.7.4.1 Alarm Record

- Before you set alarm setup information, please go to chapter 1 to connect alarm input and alarm output cable (such as light, siren and etc).
- The record priority is: Alarm>Motion detect>Regular.

In the main menu, from SETTING->EVENT-> ALARM, you can see alarm setup interface. See Figure 4-54.

- Alarm in: Here is for you to select channel number.
- Event type: There are four types. Local input/network input/IPC external/IPC offline alarm.
 - ✧ Local input alarm: The alarm signal system detects from the alarm input port.
 - ✧ Network input alarm: It is the alarm signal from the network.
 - ✧ IPC external alarm: It is the on-off alarm signal from the front-end device and can activate the local NVR.
 - ✧ IPC offline alarm: Once you select this item, system can generate an alarm when the front-end IPC disconnects with the local NVR. The alarm can activate record, PTZ, snapshot and etc. The alarm can last until the IPC and the NVR connection resumes.

- Enable: Please you need to highlight this button to enable current function.
 - Type: normal open or normal close.
- c) Click Save button to complete alarm setup interface.



Figure 4-54

- d) From Main menu->SETTING->STORAGE->SCHEDULE, you can go to Figure 4-44.
- e) Select alarm channel, period and the record type shall be alarm. Please refer to chapter 4.7.2.
- f) Click Copy button to copy current setup to other channel(s).
- g) Click OK button to save alarm record information.

4.7.4.2 Alarm Snapshot

- a) Please refer to Step a) to step c) of chapter 4.7.3.2 to enable timing snapshot.
- b) From Main menu->SETTING->STORAGE->SCHEDULE, you can go to Figure 4-55 to enable snapshot function.
- c) From Main menu->SETTING->EVENT->ALARM, you can go to Figure 4-54 to set alarm parameter and enable snapshot function.
- d) Click Save button to save alarm snapshot setup.



Figure 4-55

4.7.5 Manual Record/Snapshot

You need to have proper rights to implement the following operations. Please make sure the HDD has been properly installed.

4.7.5.1 Manual Record

- a) Right click mouse and select manual record or in the main menu, from SETTING->STORAGE->RECORD. Manual record menu is shown as in Figure 4-56.

Tips


You can click Rec button on the front panel (if possible) to go to the Manual Record interface.



Figure 4-56

- b) Check the box here to select manual record channel(s). You can see the corresponding indicator light on the front panel is on.
- Channel: It is to display device all channels.
 - Manual: It has the highest priority. Enable corresponding channel to record no matter what period applied in the record setup. Now system is record general file.
 - Auto: System enables auto record function as you set in chapter 4.7.2 schedule interface (General/Motion detect/Alarm)
 - Stop: Stop current channel record/Snapshot no matter what period applied in the record setup.
 - All: Check the All box to select all channels.
- c) Click OK button to complete manual record setup.

4.7.5.2 Manual Snapshot

Click  button at the preview control bar, you can snapshot 1-5 picture(s). From main menu->SETTING->REMOTE->ENCODE->SNAPSHOT, you can set snapshot times. You can go to chapter 4.8 to view snapshot picture.

4.7.6 Holiday Record/Snapshot

It is for you to set holiday record or snapshot plan. Please note the holiday record/snapshot setup has the higher priority than the ordinary date record/snapshot setup.

4.7.6.1 Holiday Record

- a) From Main menu->SETTING->SYSTEM->GENERAL, you can go to the following interface. See Figure 4-57.




Figure 4-57

- b) Click Add new holiday button, you can see an interface shown as in Figure 4-58. Here you can set holiday date name, repeat mode, start time/end time and etc.

The 'Add Holidays' dialog box contains the following fields and options:

- Holiday Name:
- Repeat Mode: ☒ Once ☐ Always
- Holiday Range: ☒ Date ☐ Week
- Start Time:
- End Time:
- ☐ Add More

At the bottom are 'Save', 'Add', and 'Cancel' buttons.

Figure 4-58

- c) Click Add button to complete holiday setup. Now you can enable holiday setup and then click Apply button.
- d) From Main menu->SETTING->STORAGE->SCHEDULE, you can go to schedule interface. See Figure 4-59. Now you can set period and record type of holiday time. Please refer to chapter 4.7.2.1 for detailed setup information.




Figure 4-59

- e) Click OK button to set holiday record setup.

4.7.6.2 Holiday Snapshot

Set Holiday date first. Please refer to step a) to step c) of chapter 4.7.6.1.

From Main menu->SETTING->STORAGE->SCHEDULE, you can go to schedule interface. See Figure 4-59. Click Holiday item to set snapshot period.

Set holiday snapshot type (Trigger/Regular). Please refer to chapter 4.7.2.2 or chapter 4.7.3.2.

4.7.7 Other Record/Snapshot

Motion detect&Alarm record or snapshot, please refer to chapter 4.7.4.

Video loss or tampering record or snapshot function, please refer to chapter 4.7.3.

4.8 Playback and Search

4.8.1 Real-time Playback

Please refer to chapter 4.5.2 for real-time playback information.

4.8.2 Search Interface

From Main menu->Search, or on the preview interface right click mouse and then select search item, you can go to the following interface. See Figure 4-60.












Figure 4-60

Please refer to the following sheet for more information.

SN	Name	Function
1	Display window	<ul style="list-style-type: none"> ● Here is to display the searched picture or file. ● Support 1/4/9-window playback.
2	Search type	<ul style="list-style-type: none"> ● Here you can select to search the picture or the recorded file. ● You can select to play from the read-write HDD, from peripheral device or from redundancy HDD. ● Before you select to play from the peripheral device, please connect the corresponding peripheral device. You can view all record files of the root directory of the peripheral device. Click the Browse button; you can select the file you want to play. <p>Important</p> <ul style="list-style-type: none"> ● Redundancy HDD does not support picture backup function, but it supports picture playback function. You can select to play from redundancy HDD if there are pictures on the redundancy HDD.
3	Calendar	<ul style="list-style-type: none"> ● The blue highlighted date means there is picture or file. Otherwise, there is no picture or file. ● In any play mode, click the date you want to see, you can see the corresponding record file trace in the time bar.
4	Playback mode and channel selection pane.	<ul style="list-style-type: none"> ● Playback mode: 1/4/9. (It may vary due to different series.) ✧ In 1-window playback mode: you can select 1-X channels (X depends on the product channel amount). ✧ In 4-window playback mode: you can select 4 channels according to your requirement. ✧ In 9-window playback mode, you can switch between 1-8, 9-16 and etc channels.

		<ul style="list-style-type: none"> The time bar will change once you modify the playback mode or the channel option. 	
5	Card number search	<p>The card number search interface is shown as below. Here you can view card number/field setup bar. You can implement advanced search. Current series product support this function.</p>	
6	Mark file list button	<p>Click it to go to mark file list interface. You can view all mark information of current channel by time. Please refer to chapter 4.8.2.3 for detailed information. Please note only the product of this icon supports mark function.</p>	
7	File list switch button	<ul style="list-style-type: none"> Double click it, you can view the picture/record file list of current day. The file list is to display the first channel of the record file. The system can display max 128 files in one time. Use the ◀ and ▶ or the mouse to view the file. Select one item, and then double click the mouse or click the ENTER button to playback. You can input the period in the following interface to begin accurate search. File type: R—regular record; A—external alarm record; M—Motion detect record.  <ul style="list-style-type: none"> Lock file. Click the file you want to lock and click the button  to lock. The file you locked will not be overwritten. Search locked file: Click the button to view the locked file. Return: Click the button , system goes back to the calendar and channel setup interface. 	
8	Playback control pane.	▶/	<p>Play/Pause</p> <p>There are three ways for you to begin playback.</p> <ul style="list-style-type: none"> The play button Double click the valid period of the time bar. Double click the item in the file list. <p>In slow play mode, click it to switch between play/pause.</p>
		■	<p>Stop</p>
		◀	<p>Backward play</p> <p>In normal play mode, left click the button, the file begins backward play. Click it again to pause current play.</p> <p>In backward play mode, click ▶/ to restore normal play.</p>
		◀/▶	<p>In playback mode, click it to play the next or the previous section. You can click continuously when you are watching the files from the same channel.</p> <p>In normal play mode, when you pause current play, you can click ◀ and ▶ to begin frame by frame playback.</p> <p>In frame by frame playback mode, click ▶/ to restore normal playback.</p>
		▶	<p>Slow play</p> <p>In playback mode, click it to realize various slow play modes such as slow play 1, slow play 2, and etc.</p>

		 <p>Fast forward In playback mode, click to realize various fast play modes such as fast play 1, fast play 2 and etc.</p>
		Note: The actual play speed has relationship with the software version.
		 <p>Smart search</p>
		 <p>The volume of the playback</p>
		 <p>Click the snapshot button in the full-screen mode, the system can snapshot 1 picture. System supports custom snap picture saved path. Please connect the peripheral device first, click snap button on the full-screen mode, you can select or create path. Click Start button, the snapshot picture can be saved to the specified path.</p>
		 <p>Mark button. Please note this function is for some series product only. Please make sure there is a mark button in the playback control pane. You can refer to chapter 4.8.2.3 for detailed information.</p>
9	Time bar	<ul style="list-style-type: none"> ● It is to display the record type and its period in current search criteria. ● In 4-window playback mode, there are corresponding four time bars. In other playback mode, there is only one time bar. ● Use the mouse to click one point of the color zone in the time bar, system begins playback. ● The time bar is beginning with 0 o'clock when you are setting the configuration. The time bar zooms in the period of the current playback time when you are playing the file. ● The green color stands for the regular record file. The red color stands for the external alarm record file. The yellow stands for the motion detect record file.
10	Time bar unit	<ul style="list-style-type: none"> ● The option includes: 24H, 2H, 1H and 30M. The smaller the unit, the larger the zoom rate. You can accurately set the time in the time bar to playback the record. ● The time bar is beginning with 0 o'clock when you are setting the configuration. The time bar zooms in the period of the current playback time when you are playing the file.
11	Backup	<ul style="list-style-type: none"> ● Select the file(s) you want to backup from the file list. You can check from the list. Then click the backup button, now you can see the backup menu. System supports customized path setup. After select or create new folder, click the Start button to begin the backup operation. The record file(s) will be saved in the specified folder. ● Check the file again you can cancel current selection. System max supports to display 32 files from one channel. ● After you clip on record file, click Backup button you can save it. ● For one device, if there is a backup in process, you cannot start a new backup operation.
12	Clip	<ul style="list-style-type: none"> ● It is to edit the file. ● Please play the file you want to edit and then click this button when you want to

		<p>edit. You can see the corresponding slide bars in the time bar of the corresponding channel. You can adjust the slide bar or input the accurate time to set the file end time.</p> <ul style="list-style-type: none"> ● After you set, you can click Clip button again to edit the second period. You can see the slide bar restore its previous position. ● Click Backup button after clip, you can save current contents in a new file. ● You can clip for one channel or multiple-channel. The multiple-channel click operation is similar with the one-channel operation. <p>Please note:</p> <ul style="list-style-type: none"> ● System max supports 1024 files backup at the same time. ● You cannot operate clip operation if there is any file has been checked in the file list.
13	Record type	In any play mode, the time bar will change once you modify the search type.
Other Functions		
14	Smart search	<ul style="list-style-type: none"> ● When system is playing, you can select a zone in the window to begin smart search. Click the motion detect button to begin play. ● Once the motion detect play has begun, click button again will terminate current motion detect file play. ● There is no motion detect zone by default. ● If you select to play other file in the file list, system switches to motion detect play of other file. ● During the motion detect play process, you cannot implement operations such as change time bar, begin backward playback or frame by frame playback. ● Please refer to chapter 4.8.2.1 Smart Search for detailed operation.
15	Other channel synchronization switch to play when playback	When playing the file, click the number button, system can switch to the same period of the corresponding channel to play.
16	Digital zoom	When the system is in full-screen playback mode, left click the mouse in the screen. Drag your mouse in the screen to select a section and then left click mouse to realize digital zoom. You can right click mouse to exit.
17	Manually switch channel when playback	<p>During the file playback process, you can switch to other channel via the dropdown list or rolling the mouse.</p> <p>This function is null if there is no record file or system is in smart search process.</p>

Note:

All the operations here (such as playback speed, channel, time and progress) have relationship with

hardware version. Some series NVRs do not support some functions or playback speeds.

4.8.2.1 Smart Search



During the multiple-channel playback mode, double click one channel and then click the  button, system begins smart search. System supports 396(22*18 PAL) and 330(22*15 NTSC) zones. Please left click mouse to select smart search zones. See Figure 4-61.



Figure 4-61


Click the , you can go to the smart search playback. Click it again, system stops smart search playback.

Important

- **System does not support motion detect zone setup during the full-screen mode.**
- **During the multiple-channel playback, system stops playback of rest channels if you implement one-channel smart search.**

4.8.2.2 Accurate playback by time

Select records from one day, click the list, you can go to the file list interface. You can input time at the top right corner to search records by time. See image on the left side of the Figure 4-62 For example, input

time 11:00.00 and then click Search button , you can view all the record files after 11:00.00 (The records includes current time.). See image on the right side of the Figure 4-62 Double click a file name to playback.

Note

- After you searched files, system implement accurate playback once you click Play for the first time.
- System does not support accurate playback for picture.
- System supports synchronization playback and non-synchronous playback. The synchronization playback supports all channels and non-synchronous playback only supports accurately playback of current select channel.




Figure 4-62

4.8.2.3 Mark Playback

Please make sure your purchased device support this function. You can use this function only if you can see the mark playback icon on the Search interface (Figure 4-60).

When you are playback record, you can mark the record when there is important information. After playback, you can use time or the mark key words to search corresponding record and then play. It is very easy for you to get the important video information.

- Add Mark

When system is playback, click Mark button , you can go to the following interface. See Figure 4-63.





Figure 4-63

- Playback Mark

During 1-window playback mode, click mark file list button  in Figure 4-60, you can go to mark file list interface. Double click one mark file, you can begin playback from the mark time.


- Play before mark time

Here you can set to begin playback from previous N seconds of the mark time.

Note

Usually, system can playbacks previous N seconds record if there is such kind of record file. Otherwise, system playbacks from the previous X seconds when there is such as kind of record.

- Mark Manager

Click the mark manager button  on the Search interface (Figure 4-60); you can go to Mark Manager interface. See Figure 4-64. System can manage all the record mark information of current channel by default. You can view all mark information of current channel by time.



The screenshot shows the 'Mark Manager' interface. At the top, there's a title bar 'Mark Manager'. Below it, there's a 'Channel' dropdown menu set to '1'. There are two time input fields: 'Start Time' set to '2014 - 07 - 09 00 : 00 : 00' and 'End Time' set to '2014 - 07 - 10 00 : 00 : 00'. A 'Search' button is to the right of the 'End Time' field. Below these fields is a table with the following data:

	<input type="checkbox"/>	Channel	Mark Time	Mark Name
1	<input type="checkbox"/>	1	2014-07-09 00:00:05	report

At the bottom of the interface, there are two buttons: 'Delete' on the left and 'Logout' on the right.

Figure 4-64

- Modify

Double click one mark information item, you can see system pops up a dialogue box for you to change mark information. You can only change mark name here.

- Delete

Here you can check the mark information item you want to delete and then click Delete button, you can remove one mark item. .

Note

- After you go to the mark management interface, system needs to pause current playback. System resume playback after you exit mark management interface.
- If the mark file you want to playback has been removed, system playbacks from the first file in the list.

4.8.3 Picture Playback

- a) From Main menu->Search, or on the preview interface right click mouse, you can go to Figure 4-60.
- b) At the top right pane, you can check the box to select picture and then select playback interval.
- c) Please refer to chapter 4.8.2 to select picture you want to view.

4.9 Backup

4.9.1 File Backup

In this interface, you can backup record file to the USB device.

- a) Connect USB burner, USB device or portable HDD and etc to the device.
- b) From Main menu->BACKUP, you can go to the Backup interface. See Figure 4-65

The screenshot shows the 'BACKUP' interface with the following elements:

- A title bar with the word 'BACKUP'.
- A file path input field showing '/' and a 'Browse' button.
- Space usage indicators: '0.00 KB(Space Needed)' and '0.00 KB/0.00 KB(Free/Total)'.
- A 'Type' dropdown menu set to 'All'.
- 'Start Time' and 'End Time' fields with calendar icons, showing '2014 - 07 - 09' and '00 : 00 : 00' respectively.
- 'Record CH' dropdown set to '1'.
- 'File Format' dropdown set to 'DAV'.
- 'Add' and 'Remove' buttons.
- A table with columns: '0', 'Channel', 'Type', 'Start Time', 'End Time', 'Size(KB)', and 'Play'.
- A 'Start' button at the bottom right.

0	Channel	Type	Start Time	End Time	Size(KB)	Play

Figure 4-65

- c) Select backup device and then set channel, file start time and end time.
- d) Click Add button, system begins search. All matched files are listed below. System automatically calculates the capacity needed and remained. See Figure 4-66.
- e) System only backup files with check mark before channel name. You can use Fn or cancel button to delete check mark after file serial number.
- f) Click backup button, you can backup selected files. There is a process bar for you reference.
- g) When the system completes backup, you can see a dialogue box prompting successful backup.



Figure 4-66

- h) Click backup button, system begins burning. At the same time, the backup button becomes stop button. You can view the remaining time and process bar at the left bottom.

Note

- During backup process, you can click ESC to exit current interface for other operation (For some series product only). The system will not terminate backup process.
- The file name format usually is: Channel number+Record type+Time. In the file name, the YDM format is Y+M+D+H+M+S. File extension name is .dav.

4.9.2 Import/Export

This function allows you to copy current system configuration to other devices. It also supports import, create new folder, and delete folder and etc function.

From Main menu->SETTING->SYSTEM->IMP/EXP, you can see the configuration file backup interface is shown as below. See Figure 4-67.




Figure 4-67

- Export: Please connect the peripheral device first and then go to the following interface. Click Export button, you can see there is a corresponding “Config_Time” folder. Double click the folder, you can view some backup files.
- Import: Here you can import the configuration files from the peripheral device to current device. You need to select a folder first. You can see a dialogue box asking you to select a folder if you are selecting a file. System pops up a dialogue box if there is no configuration file under current folder. After successfully import, system needs to reboot to activate new setup.
- Format: Click Format button, system pops up a dialogue box for you to confirm current operation. System begins format process after you click the OK button.

Note:


- System cannot open config backup interface again if there is backup operation in the process.
- System refreshes device when you go to the config backup every time and set current directory as the root directory of the peripheral device.
- If you go to the configuration backup interface first and then insert the peripheral device, please click Refresh button to see the newly added device.

4.9.3 Backup Log

- a) From Main menu->INFO->LOG, the interface is shown as below. See Figure 4-68.



Figure 4-68

- b) Select log type and then set start time/end time, click Search button, you can see log time and event information. Click  to view detailed log information.
- c) Select log items you want to save and then click backup button, you can select a folder to save them. Click Start to backup and you can see the corresponding dialogue box after the process is finish.

4.9.4 USB Device Auto Pop-up

After you inserted the USB device, system can auto detect it and pop up the following dialogue box. It allows you to conveniently backup file, log, configuration or update system. See Figure 4-69. Please refer to chapter 4.9.1 file backup, chapter 4.9.3 backup log, chapter 4.9.2 import/export, and chapter 4.8.2 search for detailed information.



Figure 4-69

4.10 Alarm

4.10.1 Detect Alarm

In the main menu, from Setting to Detect, you can see motion detect interface. See Figure 4-70. There are three detection types: motion detection, video loss, tampering.

4.10.1.1 Motion Detect


After analysis video, system can generate a motion detect alarm when the detected moving signal reached the sensitivity you set here.

Detection menu is shown as below. See Figure 4-70.

- Event type: From the dropdown list you can select motion detection type.
- Channel: Select a channel from the dropdown list to set motion detect function.
- Enable: Check the box here to enable motion detect function.
- Region: Click select button, the interface is shown as in Figure 4-71. Here you can set motion detection zone. There are four zones for you to set. Please select a zone first and then left drag the mouse to select a zone. The corresponding color zone displays different detection zone. You can click Fn button to switch between the arm mode and disarm mode. In arm mode, you can click the direction buttons to move the green rectangle to set the motion detection zone. After you completed the setup, please click ENTER button to exit current setup. Do remember click save button to save current setup. If you click ESC button to exit the region setup interface system will not save your zone setup.
- Sensitivity: System supports 6 levels. The sixth level has the highest sensitivity.
- Anti-dither: Here you can set anti-dither time. The value ranges from 0 to 600s. The anti-dither time refers to the alarm signal lasts time. It can be seem as the alarm signal activation stays such as the buzzer, tour, PTZ activation, snapshot, channel record. The stay time here does not include the latch time. During the alarm process, the alarm signal can begin an anti-dither time if system detects the local alarm again. The screen prompt, alarm upload, email and etc will not be activated. For example, if you set the anti-dither time as 10 second, you can see the each activation may last 10s if the local

alarm is activated. During the process, if system detects another local alarm signal at the fifth second, the buzzer, tour, PTZ activation, snapshot, record channel will begin another 10s while the screen prompt, alarm upload, email will not be activated again. After 10s, if system detects another alarm signal, it can generate an alarm since the anti-dither time is out.

- **Period:** Click set button, you can see an interface is shown as in Figure 4-73. Here you can set motion detect period. System only enables motion detect operation in the specified periods. It is not for video loss or the tampering. There are two ways for you to set periods. Please note system only supports 6 periods in one day.
- **Alarm output:** when an alarm occurs, system enables peripheral alarm devices.
- **Latch:** when motion detection complete, system auto delays detecting for a specified time. The value ranges from 1-300(Unit: second)
- **Show message:** System can pop up a message to alarm you in the local host screen if you enabled this function.
- **Alarm upload:** System can upload the alarm signal to the network (including alarm centre) if you enabled current function.
- **Send email:** System can send out email to alert you when an alarm occurs.
- **Record channel:** System auto activates motion detection channel(s) to record once an alarm occurs. Please make sure you have set MD record in Schedule interface(Main Menu->SETTING->SCHEDULE) and schedule record in manual record interface(Main Menu->ADVANCED->MANUAL RECORD)
- **PTZ activation:** Here you can set PTZ movement when an alarm occurs. Such as go to preset, tour & pattern when there is an alarm. Click “select” button, you can see an interface is shown as in Figure 4-72.
- **Record Delay:** System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.
- **Tour:** Here you can enable tour function when alarm occurs. System one-window tour.
- **Snapshot:** You can enable this function to snapshot image when a motion detect alarm occurs.
- **Video matrix** Check the box here to enable this function. When an alarm occurs, SPOT OUT port displays device video output. It displays video (1-window tour) from alarm activation channel you select at the Record channel item.
- **Buzzer:** Highlight the icon to enable this function. The buzzer beeps when alarm occurs.

Please highlight icon  to select the corresponding function. After all the setups please click save button, system goes back to the previous menu.

Note:

In motion detection mode, you cannot use copy/paste to set channel setup since the video in each channel may not be the same.

In Figure 4-71, you can left click mouse and then drag it to set a region for motion detection. Click Fn to switch between arm/withdraw motion detection. After setting, click enter button to exit.



Figure 4-70





Figure 4-71



The PTZ Activation window features a title bar with a 'PTZ Activation' button. Below the title bar, there are eight rows, each representing a channel. Each row contains a label (Channel 1 through Channel 8), a dropdown menu currently set to 'None', and a numeric input field set to '0'. At the bottom right of the window are 'OK' and 'Cancel' buttons.

Channel	PTZ Mode	Value
Channel 1	None	0
Channel 2	None	0
Channel 3	None	0
Channel 4	None	0
Channel 5	None	0
Channel 6	None	0
Channel 7	None	0
Channel 8	None	0

Figure 4-72



The Setup window has a title bar with a 'Setup' button. It displays a 24-hour timeline at the top, with major ticks every 2 hours (0, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24). Below the timeline, there are eight rows for scheduling: 'All', 'Sun', 'Mon', 'Tue', 'Wed', 'Thu', 'Fri', 'Sat', and 'Holiday'. Each row consists of a checkbox, a yellow bar representing the active period, and a 'Setup' button. The 'All' checkbox is checked. At the bottom left is a 'Default' button, and at the bottom right are 'OK' and 'Cancel' buttons.

Day/Category	Active Period (Hours)	Action
<input checked="" type="checkbox"/> All	0 - 24	Setup
<input type="checkbox"/> Sun	0 - 24	Setup
<input type="checkbox"/> Mon	0 - 24	Setup
<input type="checkbox"/> Tue	0 - 24	Setup
<input type="checkbox"/> Wed	0 - 24	Setup
<input type="checkbox"/> Thu	0 - 24	Setup
<input type="checkbox"/> Fri	0 - 24	Setup
<input type="checkbox"/> Sat	0 - 24	Setup
<input type="checkbox"/> Holiday	0 - 24	Setup

Figure 4-73

Figure 4-74

Motion detect here only has relationship with the sensitivity and region setup. It has no relationship with other setups.

4.10.1.2 Tampering

When someone viciously masks the lens, or the output video is in one-color due to the environments light change, the system can alert you to guarantee video continuity. Tampering interface is shown as in Figure 4-75. You can enable “Alarm output “or “Show message” function when tampering alarm occurs.

- Sensitivity: The value ranges from 1 to 6. It mainly concerns the brightness. The level 6 has the higher sensitivity than level 1. The default setup is 3.

Tips:

You can enable preset/tour/pattern activation operation when video loss occurs.

Please refer to chapter 4.10.1.1 motion detection for detailed information.

Note:

- In Detect interface, copy/paste function is only valid for the same type, which means you cannot copy a channel setup in video loss mode to tampering mode.
- About Default function. Since detection channel and detection type may not be the same, system can only restore default setup of current detect type. For example, if you click Default button at the tampering interface, you can only restore default tampering setup. It is null for other detect types.
- System only enables tampering function during the period you set here. It is null for motion detect or video loss type.



Figure 4-75

4.10.1.3 Video Loss

In Figure 4-70, select video loss from the type list. You can see the interface is shown as in Figure 4-76. This function allows you to be informed when video loss phenomenon occurred. You can enable alarm output channel and then enable show message function.

You can refer to chapter 4.10.1.1 Motion Detect for detailed information.

Tips:

You can enable preset/tour/pattern activation operation when video loss occurs.



Figure 4-76

4.10.2 Alarm output

From Main menu->SETTING->EVENT->ALARM OUTPUT, you can see an interface shown as in Figure 4-77.

Here is for you to set proper alarm output (Auto/manual/stop).

Click OK button of the alarm reset, you can clear all alarm output status.



Figure 4-77

Please highlight icon  to select the corresponding alarm output.

After all the setups please click OK button, system goes back to the previous menu.

4.10.3 Alarm Setup

In the main menu, from SETTING->EVENT->ALARM, you can see alarm setup interface.

- Alarm in: Here is for you to select channel number.

In the main menu, from SETTING->EVENT->ALARM, you can see alarm setup interface. See Figure 4-78.

There are four alarm types. See Figure 4-78 to Figure 4-81.

- ✧ Local alarm: The alarm signal system detects from the alarm input port.
- ✧ Network alarm: It is the alarm signal from the network.
- ✧ IPC external alarm: It is the on-off alarm signal from the front-end device and can activate the local HNVR.
- ✧ IPC offline alarm: Once you select this item, system can generate an alarm when the front-end IPC disconnects with the local HNVR. The alarm can activate record, PTZ, snap and etc. The alarm can last until the IPC and the HNVR connection resumes.

Important

- If it is your first time to boot up the device, the disconnection status of the front-end network camera will not be regarded as offline. After one successfully connection, all the disconnection events will be regarded as IPC offline event.
- When IPC offline alarm occurs, the record and snapshot function of digital channel is null.
- Enable: Please you need to highlight this button to enable current function.
- Type: normal open or normal close.

- Period: Click set button, you can see an interface is shown as in Figure 4-83. There are two ways for you to set periods. There are max 6 periods in one day. There are four record types: regular, motion detection (MD), Alarm, MD & alarm.
- PTZ activation: When an alarm occurred, system can activate the PTZ operation. The PTZ activation lasts an anti-dither period. See Figure 4-82.
- Anti-dither: Here you can set anti-dither time. The value ranges from 0 to 600s. The anti-dither time refers to the alarm signal lasts time. It can be seem as the alarm signal activation stays such as the buzzer, tour, PTZ activation, snapshot, channel record. The stay time here does not include the latch time. During the alarm process, the alarm signal can begin an anti-dither time if system detects the local alarm again. The screen prompt, alarm upload, email and etc will not be activated. For example, if you set the anti-dither time as 10 second, you can see the each activation may last 10s if the local alarm is activated. During the process, if system detects another local alarm signal at the fifth second, the buzzer, tour, PTZ activation, snapshot, record channel will begin another 10s while the screen prompt, alarm upload, email will not be activated again. After 10s, if system detects another alarm signal, it can generate an alarm since the anti-dither time is out.
- Alarm output: The number here is the device alarm output port. You can select the corresponding ports(s) so that system can activate the corresponding alarm device(s) when an alarm occurred.
- Latch: When the anti-dither time ended, the channel alarm you select in the alarm output may last the specified period. The value ranges from 1 to 300 seconds. This function is not for other alarm activation operations. The latch is still valid even you disable the alarm event function directly.
- Show message: System can pop up a message to alarm you in the local host screen if you enabled this function.
- Alarm upload: System can upload the alarm signal to the network (including alarm centre and the WEB) if you enabled current function. System only uploads the alarm channel status. You can go to the WEB and then go to the Alarm interface to set alarm event and alarm operation. Please go to the Network interface to set alarm centre information.
- Send email: System can send out the alarm signal via the email to alert you when alarm occurs. Once you enable the snap function, system can also send out an image as the attachment. Please go to the Main Menu->SETTING ->NETWORK->Email interface to set.
- Record channel: you can select proper channel to record alarm video (Multiple choices).
 - ✧ You need to set alarm record mode as Schedule in Record interface (Main Menu->Advanced->Record). Please note the manual record has the highest priority. System record all the time no matter there is an alarm or not if you select Manual mode.
 - ✧ Now you can go to the Schedule interface (Main Menu->SETTING->SCHEDULE) to set the record type, corresponding channel number, week and date. You can select the record type:Regular/MD/Alarm/MD&Alarm. Please note, you cannot select the MD&Alarm and MD(or Alarm) at the same time.
 - ✧ Now you can go to the Encode interface to select the alarm record and set the encode parameter (Main Menu->SETTING->AUDIO/VIDEO).
 - ✧ Finally, you can set the alarm input as the local alarm and then select the record channel. The select channel begins alarm record when an alarm occurred. Please note system begins the alarm record instead of the MD record if the local alarm and MD event occurred at the same time.
- Tour: Here you can enable tour function when an alarm occurs. System supports 1/8-window tour. Please go to chapter4.5.4.2. Display for tour interval setup. Please note the tour setup here has

higher priority than the tour setup you set in the Display interface. Once there two tours are both enabled, system can enable the alarm tour as you set here when an alarm occurred. If there is no alarm, system implements the tour setup in the Display interface.

- Snapshot: You can enable this function to snapshot image when an alarm occurs.
- Buzzer: Highlight the icon to enable this function. The buzzer beeps when an alarm occurs.



Figure 4-78



Figure 4-79



Figure 4-80



Figure 4-81

PTZ Activation

Channel 1	<div>None</div>	<div>0</div>	Channel 2	<div>None</div>	<div>0</div>
Channel 3	<div>None</div>	<div>0</div>	Channel 4	<div>None</div>	<div>0</div>
Channel 5	<div>None</div>	<div>0</div>	Channel 6	<div>None</div>	<div>0</div>
Channel 7	<div>None</div>	<div>0</div>	Channel 8	<div>None</div>	<div>0</div>

OK

Cancel

Figure 4-82

The screenshot shows the 'Setup' screen of the 'Clock' app. At the top, there is a 'Setup' button. Below it, there is a list of days of the week and a 'Holiday' option. Each option has a corresponding bar chart showing the number of hours per day. The 'Sun' bar chart shows a red bar from 0 to 14, indicating 14 hours. The 'Mon' through 'Sat' bar charts show red bars from 0 to 24, indicating 24 hours. The 'Holiday' bar chart shows a red bar from 0 to 24, indicating 24 hours. A 'Setup' button is next to each bar chart. At the bottom, there are 'Default', 'OK', and 'Cancel' buttons.

Day	Hours (0-24)	Setup Button
All	0-24	Setup
Sun	0-14	Setup
Mon	0-24	Setup
Tue	0-24	Setup
Wed	0-24	Setup
Thu	0-24	Setup
Fri	0-24	Setup
Sat	0-24	Setup
Holiday	0-24	Setup

Default OK Cancel

Figure 4-83

Period

Current Date: Sun

Period 1

00 : 00 - 24 : 00

☒

Period 2

00 : 00 - 24 : 00

☐

Period 3

00 : 00 - 24 : 00

☐

Period 4

00 : 00 - 24 : 00

☐

Period 5

00 : 00 - 24 : 00

☐

Period 6

00 : 00 - 24 : 00


☐

Copy

☐ All ☒ Sun ☐ Mon ☐ Tue ☐ Wed ☐ Thu ☐ Fri ☐ Sat ☐ Holiday

Save

Figure 4-84

Please highlight icon  to select the corresponding function. After setting all the setups please click save button, system goes back to the previous menu.

4.10.4 Abnormality

There are two types: Disk/Network.

- ✧ Disk: Disk error, no disk, no space. See Figure 4-85 and Figure 4-86.
- ✧ Network: Disconnection, IP conflict, MAC conflict. See Figure 4-87.
- Alarm output: Please select alarm activation output port (multiple choices).
- Less than: System can alarm you when the HDD space is less than the threshold you set here (For HDD no space type only).
- Latch: Here you can set corresponding delaying time. The value ranges from 1s-300s. System automatically delays specified seconds in turning off alarm and activated output after external alarm cancelled.
- Show message: system can pop up the message in the local screen to alert you when alarm occurs.
- Alarm upload: System can upload the alarm signal to the network (including alarm centre) if you enabled current function. For disconnection event, IP conflict event and MAC conflict event, this function is null.
- Send email: System can send out email to alert you when alarm occurs.
- Buzzer: Highlight the icon to enable this function. The buzzer beeps when an alarm occurs.




Figure 4-85



Figure 4-86



Figure 4-87

4.11 Network

4.11.1 Basic Setup

The single network adapter interface is shown as in Figure 4-88 .

- IP Version: There are two options: IPv4 and IPv6. Right now, system supports these two IP address format and you can access via them.
- MAC address: The host in the LAN can get a unique MAC address. It is for you to access in the LAN. It is read-only.
- IP address: Here you can use up/down button (▲▼) or input the corresponding number to input IP address. Then you can set the corresponding subnet mask the default gateway.
- Default gateway: Here you can input the default gateway. Please note system needs to check the validity of all IPv6 addresses. The IP address and the default gateway shall be in the same IP section. That is to say, the specified length of the subnet prefix shall have the same string.
- DHCP: It is to auto search IP. When enable DHCP function, you cannot modify IP/Subnet mask /Gateway. These values are from DHCP function. If you have not enabled DHCP function, IP/Subnet mask/Gateway display as zero. You need to disable DHCP function to view current IP information. Besides, when PPPoE is operating, you cannot modify IP/Subnet mask /Gateway.
- MTU: It is to set MTU value of the network adapter. The value ranges from 1280-7200 bytes. The default setup is 1500 bytes. Please note MTU modification may result in network adapter reboot and network becomes off. That is to say, MTU modification can affect current network service. System may pop up dialog box for you to confirm setup when you want to change MTU setup. Click OK button to confirm current reboot, or you can click Cancel button to terminate current modification. Before the modification, you can check the MTU of the gateway; the MTU of the NVR shall be the same as or is lower than the MTU of the gateway. In this way, you can reduce packets and enhance network transmission efficiency.

The following MTU value is for reference only.

- ✧ 1500: Ethernet information packet max value and it is also the default value. It is the typical setup when there is no PPPoE or VPN. It is the default setup of some router, switch or the network adapter.
- ✧ 1492: Recommend value for PPPoE.
- ✧ 1468: Recommend value for DHCP.
- Preferred DNS server: DNS server IP address.
- Alternate DNS server: DNS server alternate address.

After completing all the setups please click save button, system goes back to the previous menu.



Figure 4-88

4.11.1.1 Connection

The connection setup interface is shown as in Figure 4-89.

- Max connection: system support maximal 128 users. 0 means there is no connection limit.
- TCP port: Default value is 37777.
- UDP port: Default value is 37778.
- HTTP port: Default value is 80.
- HTTPS port: Default value is 443.
- RTSP port: Default value is 554.

Important: System needs to reboot after you changed and saved any setup of the above four ports. Please make sure the port values here do not conflict.



Figure 4-89

4.11.1.2 WIFI

The WIFI interface is shown as below. See Figure 4-90.

- **Enable:** Check the box here to enable WIFI function.
- **Refresh:** You can click it to search the hotspot list again. It can automatically add the information such as the password if you have set it before.
- **Disconnect:** Here you can click it to turn off the connection.
- **Connect:** Here you can click it to connect to the hotspot. System needs to turn off current connection and then connect to a new hotspot if there is connection of you selected one.




Figure 4-90

- WIFI working status: Here you can view current connection status.

Please note:

- After successful connection, you can see WIFI connection icon at the top right corner of the preview interface.
- When the hotspot verification type is WEP, system displays as AUTO since the device cannot detect its encryption type.
- System does not support verification type WPA and WPA2. The display may become abnormal for the verification type and encryption type.

After device successfully connected to the WIFI, you can view the hotspot name, IP address, subnet mask, default gateway and etc. Right now system support TOTOLINK_N2200UP module.

4.11.1.3 3G

3G setup interface is shown as below. See Figure 4-91.

Please refer to the following contents for the parameter information.

- Pane 1: Display 3G signal intensity after you enabled 3G function.
- Pane 2: Display 3G module configuration information after you enabled 3G function.
- Pane 3: Display 3G module status information after you enabled 3G function.

It is to display current wireless network signal intensity such as EVDO, CDMA1x, WCDMA, WCDMA, EDGE and etc.

- 3G module: It is to display current wireless network adapter name.
- 3G Enable/Disable: Check the box here to enable 3G module.
- Network type: There are various network types for different 3G network modules. You can select according to your requirements.

- APN: It is the wireless connection server. It is to set you access the wireless network via which method.
- AUTH: It is the authentication mode. It supports PAP/CHAP.
- Dial number: Please input 3G network dialup number you got from your ISP.
- User name: It is the user name for you to login the 3G network.
- Password: It is the password for you to login the 3G network.
- Pulse interval: You can set dialup duration. Once you disable the extra stream, the connection time begins. For example, if you input 5 seconds here, then 3G network connection period is 5 seconds. The device automatically disconnect when time is up. If there is no extra stream, 3G network connection is valid all the time. **If the alive time is 0, then the 3G network connection is valid all the time.**
- Dial: Here you can enable or disable 3G network connection/disconnection manually.
- 3G wireless network: Here is to display wireless network status, SIM card status, dial status. If the 3G connection is OK, then you can see the device IP address the wireless network automatically allocates.




Figure 4-91

4.11.1.4 PPPoE

PPPoE interface is shown as in Figure 4-92.

Input “PPPoE name” and “PPPoE password” you get from your ISP (Internet service provider).

Click save button, you need to restart to activate your configuration.

After rebooting, NVR will connect to internet automatically. The IP in the PPPoE is the NVR dynamic value. You can access this IP to visit the unit.




Figure 4-92

4.11.1.5 DDNS Setup

DDNS setup interface is shown as in Figure 4-93.

You need a PC of fixed IP in the internet and there is the DDNS software running in this PC. In other words, this PC is a DNS (domain name server).

In network DDNS, please select DDNS type and highlight enable item. And then please input your PPPoE name you get from you IPS and server IP (PC with DDNS). Click save button and then reboot system.

Click save button, system prompts for rebooting to get all setup activated.

After rebooting, open IE and input as below:

http: //(DDNS server IP)/(virtual directory name)/webtest.htm

e.g.: http: //10.6.2.85/NVR_DDNS/webtest.htm.)

Now you can open DDNSServer web search page.




Figure 4-93

Please note DDNS type includes: CN99 DDNS, NO-IP DDNS, Quick DDNS, DynDNS DDNS and Private DDNS. All the DDNS can be valid at the same time, you can select as your requirement. Private DDNS function shall work with special DDNS server and special software.

Quick DDNS and Client-end Introduction

1) Background Introduction

Device IP is not fixed if you use ADSL to login the network. The DDNS function allows you to access the NVR via the registered domain name. Besides the general DDNS, the Quick DDNS works with the device from the manufacturer so that it can add the extension function.

2) Function Introduction

The quick DDNS client has the same function as other DDNS client end. It realizes the bonding of the domain name and the IP address. Right now, current DDNS server is for our own devices only. You need to refresh the bonding relationship of the domain and the IP regularly. There is no user name, password or the ID registration on the server. At the same time, each device has a default domain name (Generated by MAC address) for your option. You can also use customized valid domain name (has not registered.).

3) Operation

Before you use Quick DDNS, you need to enable this service and set proper server address, port value and domain name.

- Server address: www.quickddns.com
- Port number: 80
- Domain name: There are two modes: Default domain name and customized domain name.

Except default domain name registration, you can also use customized domain name (You can input your self-defined domain name.) After successful registration, you can use domain name to login installed of

the device IP.

- User name: It is optional. You can input your commonly used email address.

Important

- Do not register frequently. The interval between two registrations shall be more than 60 seconds. Too many registration requests may result in server attack.
- System may take back the domain name that is idle for one year. You can get a notification email before the cancel operation if your email address setup is OK.

4.11.1.6 UPnP

The UPNP protocol is to establish a mapping relationship between the LAN and the WAN. Please input the router IP address in the LAN in Figure 4-88. See Figure 4-94.

- UPNP on/off : Turn on or off the UPNP function of the device.
- Status: When the UPNP is offline, it shows as "Unknown". When the UPNP works it shows "Success"
- Router LAN IP: It is the router IP in the LAN.
- WAN IP: It is the router IP in the WAN.
- Port Mapping list: The port mapping list here is the one to one relationship with the router's port mapping setting.
- List:
 - ✧ Service name: Defined by user.
 - ✧ Protocol: Protocol type
 - ✧ Internal port: Port that has been mapped in the router.
 - ✧ External port: Port that has been mapped locally.
- Default: UPNP default port setting is the HTTP, TCP and UDP of the NVR.
- Add to the list: Click it to add the mapping relationship.
- Delete: Click it to remove one mapping item.

Double click one item; you can change the corresponding mapping information. See Figure 4-95.

Important:

When you are setting the router external port, please use port 1024~5000. Do not use well-known port 1~255 and the system port 256~1023 to avoid conflict.

For the TCP and UDP, please make sure the internal port and external port are the same to guarantee the proper data transmission.



Figure 4-94



Figure 4-95

4.11.1.7 IP Filter

IP filter interface is shown as in Figure 4-96. You can add IP in the following list. The list supports max 64 IP addresses. System supports valid address of IPv4 and IPv6. **Please note system needs to check the validity of all IPv6 addresses and implement optimization.**

After you enabled trusted sites function, only the IP listed below can access current NVR.

If you enable blocked sites function, the following listed IP addresses cannot access current NVR.

- Enable: Highlight the box here, you can check the trusted site function and blocked sites function. You cannot see these two modes if the Enable button is grey.

- Type: You can select trusted site and blacklist from the dropdown list. You can view the IP address on the following column.
 - Start address/end address: Select one type from the dropdown list, you can input IP address in the start address and end address. Now you can click Add IP address or Add IP section to add.
 - a) For the newly added IP address, it is in enable status by default. Remove the ☒ before the item, and then current item is not in the list.
 - b) System max supports 64 items.
 - c) Address column supports IPv4 or IPv6 format. If it is IPv6 address, system can optimize it. For example, system can optimize aa:0000: 00: 00aa: 00aa: 00aa: 00aa as aa:: aa: aa: aa: aa: aa: aa.
 - d) System automatically removes space if there is any space before or after the newly added IP address.
 - e) System only checks start address if you add IP address. System check start address and end address if you add IP section and the end address shall be larger than the start address.
 - f) System may check newly added IP address exists or not. System does not add if input IP address does not exist.
 - Delete: Click it to remove specified item.
 - Edit: Click it to edit Start IP address and/or End IP address. See Figure 4-97. System can check the IP address validity after the edit operation and implement IPv6 optimization.
 - Default: Click it to restore default setup. In this case, the trusted sites and blocked sites are both null.
- Note:**
- If you enabled trusted sites, only the IP in the trusted sites list can access the device.
 - If you enabled blocked sites, the IP in the blocked sites cannot access the device.
 - System supports add MAC address.



Figure 4-96




Figure 4-97

4.11.1.8 Email

The email interface is shown as below. See Figure 4-98.

- SMTP server: Please input your email SMTP server IP here.
- Port: Please input corresponding port value here.
- User name: Please input the user name to login the sender email box.
- Password: Please input the corresponding password here.
- Sender: Please input sender email box here.
- Title: Please input email subject here. System support English character and Arabic number. Max 32-digit.
- Receiver: Please input receiver email address here. System max supports 3 email boxes. System automatically filters same addresses if you input one receiver repeatedly.
- Interval: The send interval ranges from 0 to 3600 seconds. 0 means there is no interval.
- Health email enable: Please check the box here to enable this function. This function allows the system to send out the test email to check the connection is OK or not.
- Interval: Please check the above box to enable this function and then set the corresponding interval. System can send out the email regularly as you set here. Click the Test button, you can see the corresponding dialogue box to see the email connection is OK or not.

Please note system will not send out the email immediately when the alarm occurs. When the alarm, motion detection or the abnormality event activates the email, system sends out the email according to the interval you specified here. This function is very useful when there are too many emails activated by the abnormality events, which may result in heavy load for the email server.



Figure 4-98

4.11.1.9 FTP

You need to download or buy FTP service tool (such as Serv-U FTP SERVER) to establish FTP service. Please install Serv-U FTP SERVER first. From “start” -> “program” -> Serv-U FTP Server -> Serv-U Administrator. Now you can set user password and FTP folder. Please note you need to grant write right to FTP upload user. See Figure 4-99.




Figure 4-99

You can use a PC or FTP login tool to test setup is right or not.

For example, you can login user ZHY to FTP://10.10.7.7 and then test it can modify or delete folder or not. See Figure 4-100.





Figure 4-100

System also supports upload multiple NVRs to one FTP server. You can create multiple folders under this FTP.

FTP interface is shown as in Figure 4-101.

Please highlight the icon  in front of Enable to activate FTP function.

Here you can input FTP server address, port and remote directory. When remote directory is null, system automatically create folders according to the IP, time and channel.

User name and password is the account information for you to login the FTP.

File length is upload file length. When setup is larger than the actual file length, system will upload the whole file. When setup here is smaller than the actual file length, system only uploads the set length and auto ignore the left section. When interval value is 0, system uploads all corresponding files.

After completed channel and weekday setup, you can set two periods for one each channel.

Click the Test button, you can see the corresponding dialogue box to see the FTP connection is OK or not.



Figure 4-101

4.11.1.10 SNMP

SNMP is an abbreviation of Simple Network Management Protocol. It provides the basic network management frame of the network management system. The SNMP widely used in many environments. It is used in many network device, software and system.

You can set in the following interface. See Figure 4-102.




Figure 4-102

Please enable the SNMP function. Use the corresponding software tool (MIB Builder and MG-SOFT MIB Browser. You still need two MIB file: BASE-SNMP-MIB, NVR-SNMP-MIB) to connect to the device. You can get the device corresponding configuration information after successfully connection.

Please follow the steps listed below to configure.

- In Figure 4-102, check the box to enable the SNMP function. Input the IP address of the PC than is running the software in the Trap address. You can use default setup for the rest items.
- Compile the above mentioned two MIB file via the software MIB Builder.
- Run MG-SOFT MIB Browser to load the file from the previous step to the software.
- Input the device IP you want to manage in the MG-SOFT MIB Browser. Please set the corresponding version for your future reference.
- Open the tree list on the MG-SOFT MIB Browser; you can get the device configuration. Here you can see the device has how many video channels, audio channels, application version and etc.

Note

Port conflict occurs when SNMP port and Trap port are the same.

4.11.1.11 Multicast

Multicast setup interface is shown as in Figure 4-103.




Figure 4-103

Here you can set a multiple cast group. Please refer to the following sheet for detailed information.

- IP multicast group address
 - 224.0.0.0-239.255.255.255
 - “D” address space
 - The higher four-bit of the first byte=“1110”
- Reserved local multiple cast group address
 - 224.0.0.0-224.0.0.255
 - TTL=1 When sending out telegraph
 - For example
 - 224.0.0.1 All systems in the sub-net
 - 224.0.0.2 All routers in the sub-net
 - 224.0.0.4 DVMRP router
 - 224.0.0.5 OSPF router
 - 224.0.0.13 PIMv2 router
- Administrative scoped addressees
 - 239.0.0.0-239.255.255.255
 - Private address space
 - Like the single broadcast address of RFC1918
 - Cannot be used in Internet transmission
 - Used for multiple cast broadcast in limited space.

Except the above mentioned addresses of special meaning, you can use other addresses. For example:

Multiple cast IP: 235.8.8.36

Multiple cast PORT: 3666.

After you logged in the Web, the Web can automatically get multiple cast address and add it to the multiple cast groups. You can enable real-time monitor function to view the view.
Please note multiple cast function applies to special series only.

4.11.1.12 Alarm Center

This interface is reserved for you to develop. See Figure 4-104.



Figure 4-104

4.11.1.13 Auto register

This function allows the device to auto register to the proxy you specified. In this way, you can use the client-end to access the NVR and etc via the proxy. Here the proxy has a switch function. In the network service, device supports the server address of IPv4 or domain.

Please follow the steps listed below to use this function.

Please set proxy server address, port, and sub-device name at the device-end. Please enable the auto register function, the device can auto register to the proxy server.

1) The setup interface is shown as in Figure 4-105.

Important

Do not input network default port such as TCP port number.



Figure 4-105

2) The proxy server software developed from the SDK. Please open the software and input the global setup. Please make sure the auto connection port here is the same as the port you set in the previous step.

3) Now you can add device. Please do not input default port number such as the TCP port in the mapping port number. The device ID here shall be the same with the ID you input in Figure 4-105. Click Add button to complete the setup.

4) Now you can boot up the proxy server. When you see the network status is Y, it means your registration is OK. You can view the proxy server when the device is online.

Important

The server IP address can also be domain. But you need to register a domain name before you run proxy device server.

4.11.1.14 SWITCH

It is for you to set IP address, subnet mask, gateway and etc of the Switch. See Figure 4-106.



Figure 4-106


4.11.2 Network Test

In this interface, you can see network test and network load information.

4.11.2.1 Network Test

From main menu->INFO->NETWORK->TEST, the network test interface is shown as in Figure 4-107.

- Destination IP: Please input valid IPV4 address and domain name.
- Test: Click it to test the connection with the destination IP address. The test results can display average delay and packet loss rate and you can also view the network status as OK, bad, no connection and etc.
- Network Sniffer backup: Please insert USB2.0 device and click the Refresh button, you can view the device on the following column. You can use the dropdown list to select peripheral device. Click Browse button to select the snap path. The steps here are same as preview backup operation.

You can view all connected network adapter names (including Ethernet, PPPoE, WIFI, and 3G), you can click the button  on the right panel to begin Sniffer. Click the grey stop button to stop. Please note system cannot Sniffer several network adapters at the same time.


After Sniffer began, you can exit to implement corresponding network operation such as login WEB, monitor. Please go back to Sniffer interface to click  stop Sniffer. System can save the packets to the specified path. The file is named after "Network adapter name+time". You can use software such as Wireshark to open the packets on the PC for the professional engineer to solve complicated problems.



Figure 4-107

4.11.2.2 Network Load

From main menu->INFO->NETWORK->LOAD, network load is shown as in Figure 4-108. Here you can view the follow statistics of the device network adapter.

Here you can view information of all connected network adapters. The connection status is shown as offline if connection is disconnected. Click one network adapter, you can view the flow statistics such as send rate and receive rate at the top panel



Figure 4-108

4.12 HDD Setup

Here you can view HDD information such as type, status, total capacity, record time and etc. The operation includes format, resume from error, change HDD property (Read write, Read-only). Here you can also set alarm and HDD storage position.

4.12.1 Format

- From Main-menu->SETTING->STORAGE->HDD MANAGE, you can go to HDD management interface. See Figure 4-109.




Figure 4-109

- b) Select a HDD and then select format from the dropdown list. Click Execute button.
- c) Click OK button to complete the setup. You can see system needs to restart to activate current setup.

4.12.2 HDD Information

Here is to list hard disk type, total space, free space, and status. See Figure 4-110.

○ means current HDD is normal. - means there is no HDD.

If disk is damaged, system shows as “?”. Please remove the broken hard disk before you add a new one.




Figure 4-110

In Figure 4-110, click one HDD item, the S.M.A.R.T interface is shown as in Figure 4-111.



Figure 4-111

Parameter	Function
SATA	1 here means there is 1 HDD. For different series product, the max HDD amount may vary, When HDD is working properly, system is shown as O. . “_” means there is no HDD.
SN	You can view the HDD amount the device connected to; * means the second HDD is current working HDD.
Type	The corresponding HDD property.
Total space	The HDD total capacity.
Free space	The HDD free capacity.
Status	HDD can work properly or not.
Bad track	Display there is bad track or not.
Page up	Click it to view previous page.
Page down	Click it to view the next page.
View recording time	Click it to view HDD record information (file start time and end time).
View HDD type and capability	Click it to view HDD property, status and etc,

4.12.3 Advanced

It is to set HDD group, and HDD group setup for main stream, extra stream and snapshot operation

Important

HDD group and quota mode cannot be valid at the same time. System needs to restart once you change the mode here.

The HDD group mode is shown as in Figure 4-112.

- HDD: Here you can view the HDD amount the device can support.
- Group: It lists the HDD Group number of current hard disk.



Figure 4-112

Please select the correspond group from the dropdown list and then click Apply button.
Click main stream/sub stream/Snapshot button to set corresponding HDD group information. See Figure 4-113 through Figure 4-115.



Figure 4-113




Figure 4-114



Figure 4-115

4.13 Basic Setups

Set NVR basic setup, device setup and other setups.

4.13.1 Device Setup

From Main menu->SETTING->SYSTEM->GENERAL, you can go to the general interface. See Figure 4-117.

- Device Name: Please input a corresponding device name here.
- Device No: When you are using one remote control (not included in the accessory bag) to control several NVRs, you can give a name to each NVR for your management.
- Language: System supports two languages: English and Chinese (simplified)
- Video standard: There are two formats: NTSC and PAL.
- HDD full: Here is for you to select working mode when hard disk is full. There are two options: stop recording or overwrite. If current working HDD is overwritten or the current HDD is full while the next HDD is no empty, then system stops recording, If the current HDD is full and then next HDD is not empty, then system overwrites the previous files.
- Pack duration: Here is for you to specify record duration. The value ranges from 1 to 120 minutes. Default value is 60 minutes.
- Realtime play: It is to set playback time you can view in the preview interface. The value ranges from 5 to 60 minutes.
- Auto logout: Here is for you to set auto logout interval once login user remains inactive for a specified time. Value ranges from 0 to 60 minutes.
- IPC Time Sync: You can input an interval here to synchronize the NVR time and IPC time.
- Navigation bar: Check the box here, system displays the navigation bar on the interface.
- Startup wizard: Once you check the box here, system will go to the startup wizard directly when the system restarts the next time. Otherwise, it will go to the login interface.
- Mouse Sensitivity: You can set double click speed via dragging the slide bar.
- Default: You can Click Default button to restore default setup.



Figure 4-116

4.13.2 Data and Time

From Main menu->SETTING->SYSTEM->GENERAL, you can go to the general interface. See Figure 4-117.

- System time: Here is for you to set system time
- Date format: There are three types: YYYY-MM-DD: MM-DD-YYYY or DD-MM-YYYY.
- Date separator: There are three denotations to separate date: dot, beeline and solidus.
- DST: Here you can set DST time and date by week or by date. Please enable DST function and then select setup mode. Please input start time and end time and click Save button.
- Time format: There are two types: 24-hour mode or 12-hour mode.
- NTP: It is to set NTP server, port and interval.

Note:

Since system time is very important, do not modify time casually unless there is a must!

Before your time modification, please stop record operation first!

After completing all the setups please click save button, system goes back to the previous menu.



Figure 4-117

4.13.3 Holiday

Holiday setup interface is shown as in Figure 4-118. Click Add Holidays button, you can input new holiday information. See Figure 4-119. Here you can set holiday name, repeat mode and start/end time.




Figure 4-118

Figure 4-119

4.14 Device Maintenance and Manager

4.14.1 System Info

4.14.1.1 Version

From main menu->INFO->SYSTEM->VERSION, you can go to version interface.

Here is for you to view some version information. See Figure 4-120. **Please note the following figure for reference only.**

- Channel
- Alarm in
- Alarm out
- System version
- Build Date
- Web
- Serial number



Figure 4-120

4.14.1.2 BPS

Here is for you to view current video bit rate (kb/s) and resolution. See Figure 4-121.



Figure 4-121

4.14.1.3 Online User

Here is for you manage online users connected to your NVR. See Figure 4-122.

You can click button  to disconnect or block one user if you have proper system right.

System detects there is any newly added or deleted user in each five seconds and refresh the list automatically.




Figure 4-122

4.14.1.4 Remote Device Information

From main menu->INFO->EVENT, here you can view the channel status of the remote device, connection log and etc. See Figure 4-123.




Figure 4-123

4.14.1.5 Remote

4.14.1.5.1 Device Status

Here you can view the IPC status of the corresponding channel such as motion detect, video loss, tampering, alarm and etc. See Figure 4-124.





- IPC status: : Front-end does not support. : Front-end supports. : There is alarm event from current front-end.
- Connection status: : Connection succeeded. : Connection failed.
- Refresh: Click it to get latest front-end channel status.



Figure 4-124

4.14.1.5.2 Firmware

It is to view channel, IP address, manufacturer, type, system version, SN, video input, audio input, external alarm and etc. See Figure 4-125.



Figure 4-125

4.14.2 Log

From Main menu->INFO->LOG, you can go to the following interface. See Figure 4-126.

- Start time/end time: Please select start time and end time, then click search button. You can view the log files in a list. System max displays 100 logs in one page. It can max save 1024 log files.

Please use page up/down button on the interface or the front panel to view more.

Tips

Double click a log item to view its detailed information. See Figure 4-127.

Click PgUp/PgDn to view more logs.



Figure 4-126




Figure 4-127

4.14.3 Account

Here is for you to implement account management. See Figure 4-128 and Figure 4-129. Here you can:

- Add new user
- Modify user
- Add group
- Modify group
- Modify password.

For account management please note:

- For the user account name and the user group, the string max length is 6-byte. The backspace in front of or at the back of the string is invalid. There can be backspace in the middle. The string includes the valid character, letter, number, underline, subtraction sign, and dot.
- The default user amount is 64 and the default group amount is 20. System account adopts two-level management: group and user. No limit to group or user amount.
- For group or user management, there are two levels: admin and user.
- The username and group name can consist of eight bytes. One name can only be used once. There are one default username: ADMIN. The user have administrator right.
- Hidden user "default" is for system interior use only and cannot be deleted. When there is no login user, hidden user "default" automatically login. You can set some rights such as monitor for this user so that you can view some channel view without login.
- One user should belong to one group. User right cannot exceed group right.
- About reusable function: this function allows multiple users use the same account to login.

After all the setups please click save button, system goes back to the previous menu.



Figure 4-128



Figure 4-129

4.14.3.1 Add/Modify Group

Click add group button, the interface is shown as below. See Figure 4-130.

Here you can input group name and then input some memo information if necessary.

There are many rights such as control panel, shut down, real-time monitor, playback, record, record file backup, Pan/Tilt/Zoom, user account, system information view, alarm input/output setup, system setup, log view, clear log, upgrade system, control device and etc.

The modify group interface is similar to the Figure 4-130.

The screenshot shows a software interface for adding or modifying a group. At the top is a title bar with the text "Add Group". Below the title bar, there are two input fields: "Group Name" and "Memo". Underneath these fields is a section titled "Authority". This section contains three tabs: "System", "Playback", and "Monitor". The "System" tab is currently selected. Below the tabs, there is a list of permissions, each with a checked checkbox. The permissions are arranged in four columns: All, ACCOUNT, PTZ, COLOR, CAMERA, SYSTEM, INFO, STORAGE, CLEAR LOG, DISCONNECT USER, MANUAL CONTROL, EVENT, SHUTDOWN, DEFAULT&UPGRADE, BACKUP, and NETWORK. At the bottom of the interface are two buttons: "Save" and "Cancel".

Figure 4-130

4.14.3.2 Add/Modify User

Click add user button, the interface is shown as in Figure 4-131.

Please input the user name, password, select the group it belongs to from the dropdown list.

Then you can check the corresponding rights for current user.

For convenient user management, usually we recommend the general user right is lower than the admin account.

The modify user interface is similar to Figure 4-131.

Add User

User Name Reusable ☐

Password Confirm Password

Memo

Group

Authority

System Playback Monitor

<input checked="" type="checkbox"/> All	<input checked="" type="checkbox"/> SYSTEM	<input checked="" type="checkbox"/> DISCONNECT USER	<input checked="" type="checkbox"/> DEFAULT&UPGRADE
<input checked="" type="checkbox"/> ACCOUNT	<input checked="" type="checkbox"/> INFO	<input checked="" type="checkbox"/> MANUAL CONTROL	<input checked="" type="checkbox"/> BACKUP
<input checked="" type="checkbox"/> PTZ	<input checked="" type="checkbox"/> STORAGE	<input checked="" type="checkbox"/> EVENT	<input checked="" type="checkbox"/> NETWORK
<input checked="" type="checkbox"/> COLOR	<input checked="" type="checkbox"/> CLEAR LOG	<input checked="" type="checkbox"/> SHUTDOWN	
<input checked="" type="checkbox"/> CAMERA			

Save Cancel

Figure 4-131

4.14.4 Update

From Main menu->SETTING->SYSTEM->UPGRADE, you can go to the following interface. See Figure 4-132.

- Insert USB device that contain the upgrade file.
- Click Start button and then select the .bin file.
- You can see the corresponding dialogue box after the update process is complete.

SETTING

REMOTE NETWORK EVENT STORAGE **SYSTEM**

GENERAL
DISPLAY
RS232
PAN/TILT/ZOOM
ACCOUNT
AUTO MAINTAIN
IMP/EXP
DEFAULT
UPGRADE

System Upgrade

Please insert USB device and then click upgrade button to begin update, or you can select update file and then begin upgrade operation. Do not turn off the device during the upgrade process!


Upgrade

Figure 4-132

4.14.5 Default

You can restore factory default setup to fix some problems when the device is running slowly. Configuration error occurred.

From Main menu->SETTING->SYSTEM->DEFAULT, you can go to the default interface. See Figure 4-133.

Click default icon, system pops up a dialogue box. You can highlight  to restore factory default setup.

- All
- Remote Device
- Network
- Event
- STORAGE
- SYSTEM

Please highlight icon  to select the corresponding function.

After all the setups please click OK button, system goes back to the previous menu.

Warning!

After you use default function, some your customized setup may lose forever! Please think twice before you begin the operation!



Figure 4-133

4.14.6 RS232

From Main menu->SETTING->SYSTEM->RS232, RS232 interface is shown as below. There are five items. See Figure 4-134.

- Function: There are various devices for you to select. Console is for you to use the COM or mini-end software to upgrade or debug the program. The control keyboard is for you to control the device via the special keyboard. Transparent COM (adapter) is to connect to the PC to transfer data directly. Protocol COM is for card overlay function. Network keyboard is for you to use the special keyboard to control the device. Pan/Tilt/Zoom matrix is to connect to the peripheral matrix control.
- Baud rate: You can select proper baud rate.
- Data bit: You can select proper data bit. The value ranges from 5 to 8.
- Stop bit: There are three values: 1/1.5/2.
- Parity: there are five choices: none/odd/even/space mark.

System default setup is:

- Function: Console
- Baud rate:115200
- Data bit:8
- Stop bit:1
- Parity: None

After completing all the setups please click save button, system goes back to the previous menu.



Figure 4-134

4.14.7 Auto Maintain

Here you can set auto-reboot time and auto-delete old files setup. You can set to delete the files for the specified days. See Figure 4-135.

You can select proper setup from dropdown list.

After all the setups please click save button, system goes back to the previous menu.




Figure 4-135

4.14.8 Logout /Shutdown/Restart

From Main menu->OPERATION->SHUTDOWN, you can see an interface shown as in Figure 4-136.

- Shutdown: System shuts down and turns off power.
- Logout: Log out menu. You need to input password when you login the next time.
- Restart: reboot device.

If you shut down the device, system waits for 3 seconds and then shut down (You cannot cancel).

Please note, sometimes you need to input the proper password to shut down the device.



Figure 4-136

5 Web Operation

5.1 General Introduction

The device web provides channel monitor menu tree, search, alarm setup, system setup, PTZ control and monitor window and etc.

5.1.1 Preparation

Before log in, please make sure:

- Network connection is right
- NVR and PC network setup is right. Please refer to network setup(main menu->SETTING->NETWORK)
- Use order ping `***.***.***.***`(* NVR IP address) to check connection is OK or not. Usually the return TTL value should be less than 255.
- Open the IE and then input NVR IP address.
- System can automatically download latest web control and the new version can overwrite the previous one.
- If you want to un-install the web control, please run *uninstall webrec2.0.bat*. Or you can go to C:\Program Files\webrec to remove single folder. Please note, before you un-install, please close all web pages, otherwise the un-installation might result in error.
- Current series product supports various browsers such as Safari, firebox browser, Google browser. Device only support 1-channel monitor on the Apple PC.

About PoE address setup, operation and allocation.

1) Insert PoE

After you insert PoE, device may try to set a corresponding IP address of the Switch network adapter. First, system tries to set via arp ping. It then uses DHCP if it finds the DHCP is enabled. After successfully set IP address, system may use Switch to send out broadcast, system considers the connection is OK when there is any response. Now system is trying to login the newly found IPC. Now please check the interface, you can see the corresponding digital channel is active now. You can see a small PoE icon at the top left corner. You can see the PoE channel, PoE port information and etc from the connection list of the remote device interface (Chapter 4.4). For the IP search list, you need to click the IP search to display or refresh.

2) Remove PoE

After you removed PoE, you can see the corresponding digital channel becomes idle (disable). On the remote device interface, it is removed from the connected list. For the IP search list, you need to click the IP search to refresh.

3) After you insert PoE, system follows the principles listed below to map channel.

- a) If it is your first time to insert PoE, system can map it to the first idle channel. After map, the channel can memorize the MAC address of the IPC. It is a `<Channel>----<IPC mac>` map. If current channel does not connect to other device, system can memorize current MAC address, otherwise it can refresh to the newly added device and memorize the `<PoE port>----<Channel>`.
- b) If it is your second time to insert the PoE, system can check the saved MAC address according to `<Channel>----<IPC mac>` map to make sure current IPC has connected or not.

If system finds the previous information and the channel is idle, system can map it to the previously used channel. Otherwise system goes to the next step.

- c) Thirdly, according to the <PoE port>---<Channel> map, system can know the previous mapping channel of current PoE port. System can select current channel if it is free. Otherwise, it goes to the next step:
- d) Fourthly, system goes to find the first idle channel it can get.

Generally speaking, once you insert PoE, system follow the steps listed above to find the channel available.

- 4) When you insert PoE, all channels are in use now.

System can pop up a dialogue box for you to select a channel to overwrite. The title of the pop-up interface is the name of the current operation PoE port. In this interface, All PoE channel become grey and cannot select.

5.1.2 Log in

Open the IE and then input the NVR IP address in the address column.

For example, if your NVR IP address is 192.168.0.250, then please input http://192.168.0.250 in IE address column. See Figure 5-1.




Figure 5-1

System pops up warning information to ask you whether install webrec.cab control or not. Please click yes button.

If you can't download the ActiveX file, please modify your settings as follows. See Figure 5-2.




Figure 5-2

After installation, the interface is shown as below. See Figure 5-3.




Figure 5-3

Please input your username and password.

Default factory Username is **ADMIN** and Password is **12345**.

Note: For security reasons, please modify your password after you first login.

5.2 LAN Mode

For the LAN mode, after you logged in, you can see the main window. See Figure 5-8.

This main window can be divided into the following sections.

- Section 1: there are six function buttons: Live, setup (chapter 5.8), info (Chapter 5.9), playback (chapter 5.10), alarm (chapter 5.11), and logout (chapter 5.12).
- Section 2: There are monitor channels successfully connected to the NVR. Please refer to Figure 5-4 for main stream and extra stream switch information.




Figure 5-4

- Section 4: Start Talk button.

You can click this button to enable audio talk. Click 【▼】 to select bidirectional talk mode. There are four options: DEFAULT, G711a, G711u and PCM. See Figure 5-5.

After you enable the bidirectional talk, the Start talk button becomes End Talk button and it becomes green. Please note, if audio input port from the device to the client-end is using the first channel audio input port. During the bidirectional talk process, system will not encode the audio data from the 1-channel.




Figure 5-5

- Section 5: Instant record button. Click it, the button becomes green and system begins manual record. See Figure 5-6. Click it again, system restores previous record mode.



Figure 5-6

- Section 6: Local play button.

The Web can playback the saved (Extension name is dav) files in the PC-end.

Click local play button, system pops up the following interface for you to select local play file. See Figure 5-7.



Figure 5-7

- Section 7: Multi Preview button. Please refer to chapter 5.6 for detailed information.
- Section 8: PTZ operation panel. Please refer to chapter 5.4 for detailed information.
- Section 9: Image setup and alarm setup. Please refer to chapter 0 for detailed information.
- Section 10: From the left to the right ,you can see video quality/fluency/ full screen/1-window/4-window/6-window/8-window. You can set video fluency and real-time feature priority.




Figure 5-8

5.3 Real-time Monitor

In section 2, left click the channel name you want to view, you can see the corresponding video in current window.

On the top left corner, you can view device IP(172.11.10.11), channel number(1), network monitor bit

stream(2202Kbps) and stream type(M=main stream, S=sub stream). See Figure 5-9.




Figure 5-9

On the top right corner, there are six unction buttons. See Figure 5-10.




Figure 5-10

- 1: Digital zoom: Click this button and then left drag the mouse in the zone to zoom in. right click mouse system restores original status.
- 2: Local record: When you click local record button, the system begins recording and this button becomes highlighted. You can go to system folder RecordDownload to view the recorded file.
- 3: Snapshot picture: You can snapshot important video. All images are memorized in system client folder PictureDownload (default).
- 4: Audio: Turn on or off audio.(It has no relationship with system audio setup)
- 5: Close: Close video.

5.4 PTZ

Before PTZ operation, please make sure you have properly set PTZ protocol. (Please refer to chapter 5.8.5.10).

There are eight direction keys. In the middle of the eight direction keys, there is a 3D intelligent positioning key.

Click 3D intelligent positioning key, system goes back to the single screen mode. Drag the mouse in the screen to adjust section size. It can realize PTZ automatically.

Please refer to the following sheet for PTZ setup information.

Parameter	Function
Scan	<ul style="list-style-type: none"> ● Select Scan from the dropdown list. ● Click Set button, you can set scan left and right limit. ● Use direction buttons to move the camera to you desired location and then click left limit button. Then move the camera again and then click right limit button to set a right limit.
Preset	<ul style="list-style-type: none"> ● Select Preset from the dropdown list. ● Turn the camera to the corresponding position and Input the preset value. Click Add button to add a preset.

Parameter	Function
Tour	<ul style="list-style-type: none"> ● Select Tour from the dropdown list. ● Input preset value in the column. Click Add preset button, you have added one preset in the tour. ● Repeat the above procedures you can add more presets in one tour. ● Or you can click delete preset button to remove one preset from the tour.
Pattern	<ul style="list-style-type: none"> ● Select Pattern from the dropdown list. ● You can input pattern value and then click Start button to begin PTZ movement such as zoom, focus, iris, direction and etc. Then you can click Add button to set one pattern.
Aux	<ul style="list-style-type: none"> ● Please input the corresponding aux value here. ● You can select one option and then click AUX on or AUX off button.
Light wiper	You can turn on or turn off the light/wiper.




Figure 5-11

5.5 Image/Alarm-out

Select one monitor channel video and then click Image button in section 9, the interface is shown as Figure 5-12.

5.5.1 Image

Here you can adjust its view of image. (Current channel border becomes green).

Or you can click Reset button to restore system default setup.




Figure 5-12

5.5.2 Alarm output

Here you can enable or disable the alarm signal of the corresponding port. See Figure 5-13.



Figure 5-13

5.6 Multi Preview

Click Multi Preview button, the interface is shown as below. See Figure 5-14.




Figure 5-14

5.7 WAN Login

In WAN mode, after you logged in, the interface is shown as below. See Figure 5-15.




Figure 5-15

Please refer to the following contents for LAN and WAN login difference.

- 1) In the WAN mode, system opens the main stream of the first channel to monitor by default. The open/close button on the left pane is null.

2) You can select different channels and different monitor modes at the bottom of the interface. See Figure 5-16.




Figure 5-16

Important

The window display mode and the channel number are by default. For example, for the 8-channel, the max window split mode is 8.

3) Multiple-channel monitor, system adopts extra stream to monitor by default. Double click one channel, system switches to single channel and system uses main stream to monitor. You can view there are two icons at the left top corner of the channel number for you reference. M stands for main stream. S stands for sub stream (extra stream).

4) If you login via the WAN mode, system does not support alarm activation to open the video function in the Alarm setup interface.

Important

- For multiple-channel monitor mode, system adopts extra stream to monitor by default. You cannot modify manually. All channels are trying to synchronize. Please note the synchronization effect still depends on your network environments.
- For bandwidth consideration, system cannot support monitor and playback at the same time. System auto closes monitor or playback interface when you are searching setup in the configuration interface. It is to enhance search speed.

5.8 Setup

5.8.1 REMOTE

5.8.1.1 Remote Device

Remote device interface is shown as below. See Figure 5-17.

REMOTE

		IP Address	Port	Device Name	Manufacturer	Type	MAC Address
9							
1	<input type="checkbox"/>	192.168.0.113	80		Onvif		
2	<input type="checkbox"/>	192.168.0.158	80		Onvif		
3	<input type="checkbox"/>	192.168.0.163	80		Onvif		
4	<input type="checkbox"/>	192.168.0.166	80		Onvif		
5	<input type="checkbox"/>	192.168.0.168	80		Onvif		
6	<input type="checkbox"/>	192.168.0.171	80		Onvif		
7	<input type="checkbox"/>	192.168.0.205	80		Onvif		
8	<input type="checkbox"/>	192.168.0.70	80		Onvif		
9	<input type="checkbox"/>	192.168.0.85	80		Onvif		

Device Search

Add

Display Filter None

	Channel	Modify	Delete	Status	IP Address	Port	Device Name	Remote Channel No.	Manufacturer	Channel Name
<input type="checkbox"/>	1				192.168.0.113	80		1	Onvif	

Delete

Manual Add

Refresh

Figure 5-17

Manual Add

Channel

8

Manufacturer

Private

IP Address

192.168.0.0

TCP Port

37777

(1~65535)

User Name

admin

Password

•••••

Remote Channel No.

1

Decode Buffer

Default





Save

Cancel

Figure 5-18

Please refer to the following sheet for log parameter information.

Parameter	Function
Device search	Click Device search button, you can view the searched device information on the list. It includes device IP address, port, device name, manufacturer and type.

Parameter	Function
Add	Select a device in the list and then click Add button, system can connect the device automatically and add it to the Added device list. Or you can double click one item in the list to add a device.
Modify	Click  or any device in the Added device list, you can change the corresponding channel setup.
Delete	Click  , you can delete the remote connection of the corresponding channel.
Connection status	 : Connection succeeded.  : Connection failed.
Delete	Select a device in the Added device list and then click Delete button, system can disconnect the device and remove it from the Added device list.
Manual Add	<p>Click it, the interface is shown as in Figure 5-18. Here you can add network camera manually.</p> <p>You can select a channel from the dropdown list (Here only shows disconnection channel.)</p> <p>Note:</p> <ul style="list-style-type: none"> ● System supports manufactures such as Private, Panasonic, Sony, Dynacolor, Samsung, AXIS, Arecont, Dahua and Onvif standard protocol. ● If you do not input IP address here. System uses default IP 192.168.0.0 and system does not connect to this IP. ● Cannot add two devices at the same time. Click OK button here, system only connect to the corresponding device of current channel.

5.8.1.2 IMAGE

Here you can view device property information. The setups become valid immediately after you set. See Figure 5-19.




Figure 5-19

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Please select a channel from the dropdown list.
Period	It divides one day (24 hours) to two periods. You can set different hue, brightness, and contrast for different periods.
Sharpness	It is to adjust monitor video sharpness level. The default value is 50. The bigger the value is, the video image becomes sharper.
Brightness	It is to adjust monitor window brightness. The default value is 50. The larger the number is, the bright the video is. When you input the value here, the bright section and the dark section of the video will be adjusted accordingly. You can use this function when the whole video is too dark or too bright. Please note the video may become hazy if the value is too high. The value ranges from 0 to 100. The recommended value ranges from 40 to 60.
Contrast	It is to adjust monitor window contrast. The value ranges from 0 to 100. The default value is 50. The larger the number is, the higher the contrast is. You can use this function when the whole video bright is OK but the contrast is not proper. Please note the video may become hazy if the value is too low. If this value is too high, the dark section may lack brightness while the bright section may over exposure. The recommended value ranges from 40 to 60.
Saturation	It is to adjust monitor window saturation. The value ranges from 0 to 100. The default value is 50. The larger the number is, the strong the color is. This value has no effect on the general brightness of the whole video. The video color may become too strong if the value is too high. For the grey part of the video, the distortion may occur if the white balance is not accurate. Please note the video may not be attractive if the value is

	too low. The recommended value ranges from 40 to 60.
Gain	The gain adjust is to set the gain value. The smaller the value is, the low the noise is. But the brightness is also too low in the dark environments. It can enhance the video brightness if the value is high. But the video noise may become too clear.
White level	It is to enhance video effect.
Color mode	It includes several modes such as standard, color. You can select corresponding color mode here, you can see hue, brightness, and contrast and etc will adjust accordingly.
Light	It is to control light function.
Flip	It is to switch video up and bottom limit. This function is disabled by default.
Mirror	It is to switch video left and right limit. This function is disabled by default.
Profile	<p>It is to set the white balance mode. It has effect on the general hue of the video. This function is on by default.</p> <p>You can select the different scene mode such as auto, sunny, cloudy, home, office, night, disable and etc to adjust the video to the best quality.</p> <ul style="list-style-type: none"> ● Auto: The auto white balance is on. System can auto compensate the color temperature to make sure the vide color is proper. ● Sunny: The threshold of the white balance is in the sunny mode. ● Night: The threshold of the white balance is in the night mode. ● Customized: You can set the gain of the red/blue channel. The value reneges from 0 to 100.
Day/Night	<p>It is to set device color and the B/W mode switch. The default setup is auto.</p> <ul style="list-style-type: none"> ● Color: Device outputs the color video. ● Auto: Device auto select to output the color or the B/W video according to the device feature (The general bright of the video or there is IR light or not.) ● B/W: The device outputs the black and white video. ● Sensor: It is to set when there is peripheral connected IR light.

5.8.1.3 ENCODE

5.8.1.3.1 Encode

The encode interface is shown as below. See Figure 5-20.

Encode

Snapshot

Overlay

Path

Channel
1

Main Stream

Extra Stream

Code-Stream Type
Regular

Compression
H.264

Resolution
1280x720(720P)

Frame Rate(FPS)
25

Bit Rate Type
CBR

Bit Rate
2048

Video Enable
☒

Compression
MJPEG

Resolution
704x576(D1)

Frame Rate(FPS)
25

Bit Rate Type
CBR

Bit Rate
4096

Watermark Enable
☒

Watermark String
DigitalCCTV

Copy

Save

Refresh

Figure 5-20

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Please select a channel from the dropdown list.
Video enable	Check the box here to enable extra stream video. This item is enabled by default.
Code stream type	<p>It includes main stream, motion stream and alarm stream. You can select different encode frame rates form different recorded events.</p> <p>System supports active control frame function (ACF). It allows you to record in different frame rates.</p> <p>For example, you can use high frame rate to record important events, record scheduled event in lower frame rate and it allows you to set different frame rates for motion detection record and alarm record.</p>
Compression	The main bit stream supports H.264. The extra stream supports H.264, MJPEG.
Resolution	The resolution here refers to the capability of the network camera.
Frame Rate	PAL: 1 - 25fps; NTSC: 1 - 30fps.
Bit Rate	<ul style="list-style-type: none"> Main stream: You can set bit rate here to change video quality. The large the bit rate is, the better the quality is. Please refer to recommend bit rate for the detailed information. Extra stream: In CBR, the bit rate here is the max value. In dynamic video, system needs to low frame rate or video quality to guarantee the value. The value is null in VBR mode.

Reference bit rate	Recommended bit rate value according to the resolution and frame rate you have set.
I Frame	Here you can set the P frame amount between two I frames. The value ranges from 1 to 150. Default value is 50. Recommended value is frame rate.
Watermark enable	This function allows you to verify the video is tampered or not. Here you can select watermark bit stream, watermark mode and watermark character. Default character is DigitalCCTV. The max length is 85-digit. The character can only include number, character and underline.

5.8.1.3.2 Snapshot

The snapshot interface is shown as in Figure 5-21.

Figure 5-21

Please refer to the following sheet for detailed information.

Parameter	Function
Mode	There are two modes: Regular (schedule) and Trigger. <ul style="list-style-type: none"> Regular snapshot is valid during the specified period you set. Trigger snapshot only is valid when motion detect alarm, tampering alarm or local activation alarm occurs.
Image size	It is the same with the resolution of the main stream.
Quality	It is to set the image quality. There are six levels.
Snapshot Frequency	It is to set snapshot frequency. The value ranges from 1s to 7s. Or you can set customized value. The max setup is 3600s/picture.

5.8.1.3.3 Video Overlay

The video overlay interface is shown as in Figure 5-22.




Figure 5-22

Please refer to the following sheet for detailed information.

Parameter	Function
Cover-area	Check Preview or Monitor first. Click Set button, you can privacy mask the specified video in the preview or monitor video. System max supports 4 privacy mask zones.
Time Display	You can enable this function so that system overlays time information in video window. You can use the mouse to drag the time title position. You can view time title on the live video of the WEB or the playback video.
Channel Display	You can enable this function so that system overlays channel information in video window. You can use the mouse to drag the channel title position. You can view channel title on the live video of the WEB or the playback video.

5.8.1.3.4 Path

The storage path interface is shown as in Figure 5-23.


Here you can set snap image saved path ( in the preview interface) and the record storage path ( in the preview interface). The default setup is C:\PictureDownload and C:\RecordDownload. Please click the Save button to save current setup.

Figure 5-23

5.8.1.4 CAM NAME

Here you can set camera name. See Figure 5-24.

Figure 5-24

5.8.2 Network

5.8.2.1 TCP/IP

The TCP/IP interface is shown as in Figure 5-25.

Figure 5-25

Please refer to the following sheet for detailed information.

Parameter	Function
Mode	<p>There are two modes: static mode and the DHCP mode.</p> <ul style="list-style-type: none"> ● The IP/submask/gateway are null when you select the DHCP mode to auto search the IP. ● If you select the static mode, you need to set the

	IP/submask/gateway manually. <ul style="list-style-type: none"> ● If you select the DHCP mode, you can view the IP/submask/gateway from the DHCP. ● If you switch from the DHCP mode to the static mode, you need to reset the IP parameters. ● Besides, IP/submask/gateway and DHCP are read-only when the PPPoE dial is OK.
Mac Address	It is to display host Mac address.
IP Version	It is to select IP version. IPV4 or IPV6. You can access the IP address of these two versions.
IP Address	Please use the keyboard to input the corresponding number to modify the IP address and then set the corresponding subnet mask and the default gateway.
Preferred DNS	DNS IP address.
Alternate DNS	Alternate DNS IP address.
For the IP address of IPv6 version, default gateway, preferred DNS and alternate DNS, the input value shall be 128-digit. It shall not be left in blank.	
LAN Download	System can process the downloaded data first if you enable this function. The download speed is 1.5X or 2.0X of the normal speed.

5.8.2.2 Connection

The connection interface is shown as in Figure 5-26.

CONNECTION

Max Connection: 128 (0~128)

TCP Port: 37777 (1025~65535)

UDP Port: 37778 (1025~65535)

HTTP Port: 80 (1~65535)

HTTPS Port: 443 (128~65535)

RTSP Port: 554 (128~65535)

RTSP Format: rtsp://<Username>:<Password>@<IP Address>:<Port>/cam/realmonitor?channel=1&subtype=0
channel: Channel, 1-8; subtype: Code-Stream Type, Main Stream 0, Extra Stream 1.

Save Refresh Default

Figure 5-26

Please refer to the following sheet for detailed information.

Parameter	Function
Max connection	It is the max Web connection for the same device. The value ranges from 1 to 120. The default setup is 120.
TCP port	The default value is 37777. You can input the actual port number if necessary.
UDP port	The default value is 37778. You can input the actual port number if necessary.

HTTP port	The default value is 80. You can input the actual port number if necessary.
HTTPS	The default value is 443. You can input the actual port number if necessary.
RTSP port	The default value is 554.

5.8.2.3 WIFI

Please note this function is for the device of WIFI module.

The WIFI interface is shown as in Figure 5-27.

Figure 5-27

Please check the box to enable WIFI function and then click the Search SSID button. Now you can view all the wireless network information in the following list. Double click a name to connect to it. Click Refresh button, you can view latest connection status.

5.8.2.4 3G

5.8.2.4.1 CDMA/GPRS

The CDMA/GPRS Setup interface is shown as in Figure 5-28.

Figure 5-28

Please refer to the following sheet for detailed information.

Parameter	Function
WLAN type	Here you can select 3G network type to distinguish the 3G module from different ISP. The types include WCDMA, CDMA1x and etc.
APN/Dial No.	Here is the important parameter of PPP.
Authorization	It includes PAP,CHAP,NO_AUTH.
Pulse interval	It is to set time to end 3G connection after you close extra stream monitor. For example, if you input 60 here, system ends 3G connection after you close extra stream monitor 60 seconds.
Important <ul style="list-style-type: none"> ✧ If the pulse interval is 0, then system does not end 3G connection after you close the extra stream monitor. ✧ Pulse interval here is for extra stream only. This item is null if you are using main stream to monitor. 	

5.8.2.4.2 Mobile

The mobile setup interface is shown as in Figure 5-29.

Here you can activate or turn off the 3G connected phone or mobile phone, or the phone you set to get alarm message.

The screenshot shows the 'Mobile' settings page with a 'CDMA/GPRS' tab selected. It contains three main sections: 'Send SMS', 'SMS Activate', and 'Tel Activate'. Each section has a checkbox, a label, a text input field, and a large empty text area. The 'Send SMS' section has a 'Receiver' label and a 'Title' field with 'NVR Message' entered. The 'SMS Activate' section has a 'Sender' label. The 'Tel Activate' section has a 'Caller' label. At the bottom are 'Save', 'Refresh', and 'Default' buttons.

Figure 5-29

5.8.2.5 PPPoE

The PPPoE interface is shown as in Figure 5-30.

Input the PPPoE user name and password you get from the IPS (internet service provider) and enable PPPoE function. Please save current setup and then reboot the device to get the setup activated.

Device connects to the internet via PPPoE after reboot. You can get the IP address in the WAN from the IP address column.

Please note, you need to use previous IP address in the LAN to login the device. Please go to the IP address item to via the device current device information. You can access the client-end via this new address.

The screenshot shows the 'PPPoE' settings page. It has an 'Enable' checkbox. Below it are fields for 'Username', 'Password', and 'IP Address'. The 'IP Address' field is split into two rows, each showing '0 . 0 . 0 . 0'. At the bottom are 'Save', 'Refresh', and 'Default' buttons.

Figure 5-30

5.8.2.6 DDNS

The DDNS interface is shown as in Figure 5-31.

The DDNS is to set to connect the various servers so that you can access the system via the server. Please go to the corresponding service website to apply a domain name and then access the system via the domain. It works even your IP address has changed.

Please select DDNS from the dropdown list (Multiple choices). Before you use this function, please make sure your purchased device support current function.

Figure 5-31

Please refer to the following sheet for detailed information.

Parameter	Function
DDNS Type	You can select DDNS protocol from the dropdown list and then enable DDNS function.
Host IP	DDNS server IP address
Port	DDNS server port.
Domain Name	Your self-defined domain name.
User Name	The user name you input to log in the server.
Password	The password you input to log in the server.
Interval	Device sends out alive signal to the server regularly. You can set interval value between the device and DDNS server here.

Quick DDNS and Client-end Introduction

1) Background Introduction

Device IP is not fixed if you use ADSL to login the network. The DDNS function allows you to access the NVR via the registered domain name. Besides the general DDNS, the quick DDNS works with the device from the manufacturer so that it can add the extension function.

2) Function Introduction

The quick DDNS client has the same function as other DDNS client end. It realizes the bonding of the domain name and the IP address. Right now, current DDNS server is for our own devices only. You need to refresh the bonding relationship of the domain and the IP regularly. There is no user name, password or the ID registration on the server. At the same time, each device has a default domain name (Generated by MAC address) for your option. You can also use customized valid domain name (has not registered.).

3) Operation

Before you use Quick DDNS, you need to enable this service and set proper server address, port value and domain name.

- Server address: www.quickddns.com
- Port number: 80
- Domain name: There are two modes: Default domain name and customized domain name.

Except default domain name registration, you can also use customized domain name (You can input your

self-defined domain name.) After successful registration, you can use domain name to login installed of the device IP.

- User name: It is optional. You can input your commonly used email address.

Important

- Do not register frequently. The interval between two registrations shall be more than 60 seconds. Too many registration requests may result in server attack.
- System may take back the domain name that is idle for one year. You can get a notification email before the cancel operation if your email address setup is OK.

5.8.2.7 IP filter

The IP filter interface is shown as in Figure 5-32.

After you enabled trusted sites function, only the IP listed below can access current NVR.

If you enable blocked sites function, the following listed IP addresses cannot access current NVR.



Figure 5-32

5.8.2.8 Email

The email interface is shown as in Figure 5-33.

Email

☐ Enable

SMTP Server: MailServer

Port: 25

☐ Anonymous

Username:

Password:

Sender:

Encrypt Type: NONE

Subject: NVR ALERT

☒ Attachment

Receiver:

Interval: 120 Second(0~3600)

☐ Health Enable: 60 Minute (30~1440)

Test

Save Refresh Default

Figure 5-33

Please refer to the following sheet for detailed information.

Parameter	Function
Enable	Please check the box here to enable email function.
SMTP Server	Input server address and then enable this function.
Port	Default value is 25. You can modify it if necessary.
Anonymity	For the server supports the anonymity function. You can auto login anonymously. You do not need to input the user name, password and the sender information.
User Name	The user name of the sender email account.
Password	The password of sender email account.
Sender	Sender email address.
Authentication (Encryption mode)	You can select SSL or none.
Subject	Input email subject here.
Attachment	System can send out the email of the snapshot picture once you check the box here.
Receiver	Input receiver email address here. Max three addresses. It supports SSL, TLS email box.
Interval	The send interval ranges from 0 to 3600 seconds. 0 means there is no interval. Please note system will not send out the email immediately when the alarm occurs. When the alarm, motion detection or

Parameter	Function
	the abnormality event activates the email, system sends out the email according to the interval you specified here. This function is very useful when there are too many emails activated by the abnormality events, which may result in heavy load for the email server.
Health mail enable	Please check the box here to enable this function.
Update period (interval)	This function allows the system to send out the test email to check the connection is OK or not. Please check the box to enable this function and then set the corresponding interval. System can send out the email regularly as you set here.
Email test	The system will automatically sent out a email once to test the connection is OK or not .Before the email test, please save the email setup information.

5.8.2.9 FTP

The FTP interface is to set FTP information. See Figure 5-34.

Please set the FTP as your remote storage location. System can save record file or snapshot picture to the FTP once the network is offline or malfunction.

Figure 5-34

5.8.2.10 UPnP

It allows you to establish the mapping relationship between the LAN and the public network.

Here you can also add, modify or remove UPnP item. See Figure 5-35.

- In the Windows OS, From Start->Control Panel->Add or remove programs. Click the “Add/Remove Windows Components” and then select the “Network Services” from the Windows Components Wizard.
- Click the Details button and then check the “Internet Gateway Device Discovery and Control client” and “UPnP User Interface”. Please click OK to begin installation.

- Enable UPnP from the Web. If your UPnP is enabled in the Windows OS, the NVR can auto detect it via the “My Network Places”

UPnP

PAT ☒ Enable ☐ Disable

Status

LAN IP

WAN IP

No.	<input checked="" type="checkbox"/>	Service Name	Protocol	Internal Port	External Port	Modify	Delete
1	<input checked="" type="checkbox"/>	HTTP	TCP	80	80		
2	<input checked="" type="checkbox"/>	TCP	TCP	37777	37777		
3	<input checked="" type="checkbox"/>	UDP	UDP	37778	37778		
4	<input checked="" type="checkbox"/>	RTSP	UDP	554	554		
5	<input checked="" type="checkbox"/>	RTSP	TCP	554	554		
6	<input checked="" type="checkbox"/>	SNMP	UDP	161	161		
7	<input checked="" type="checkbox"/>	HTTPS	TCP	443	443		

Figure 5-35

5.8.2.11 SNMP

The SNMP interface is shown as in Figure 5-36.

The SNMP allows the communication between the network management work station software and the proxy of the managed device. It is reserved for the 3rd party to develop.

SNMP

☐ Enable

SNMP Port (0~65535)

Read Community

Write Community

Trap Address

Trap Port (0~65535)

SNMP Version ☒ V1 ☒ V2

Figure 5-36

Please refer to the following sheet for detailed information.

Parameter	Function
SNMP Port	The listening port of the proxy program of the device. It is a UDP port not a TCP port. The value ranges from 1 to 65535. The default value is 161

Parameter	Function
Read Community	It is a string. It is a command between the manage process and the proxy process. It defined the authentication, access control and the management relationship between one proxy and one group of the managers. Please make sure the device and the proxy are the same. The read community will read all the objects the SNMP supported in the specified name. The default setup is public.
Write Community	It is a string. It is a command between the manage process and the proxy process. It defined the authentication, access control and the management relationship between one proxy and one group of the managers. Please make sure the device and the proxy are the same. The read community will read/write/access all the objects the SNMP supported in the specified name. The default setup is write.
Trap address	The destination address of the Trap information from the proxy program of the device.
Trap port	The destination port of the Trap information from the proxy program of the device. It is for the gateway device and the client-end PC in the LAN to exchange the information. It is a non-protocol connection port. It has no effect on the network applications. It is a UDP port not TCP port. The value ranges from 1 to 165535. The default value is 162.
SNMP version	<ul style="list-style-type: none"> ● Check V1, system only processes the information of V1. ● Check V2, system only processes the information of V2.

5.8.2.12 Multicast

The multicast interface is shown as in Figure 5-37.

Multicast is a transmission mode of data packet. When there is multiple-host to receive the same data packet, multiple-cast is the best option to reduce the broad width and the CPU load. The source host can just send out one data to transit. This function also depends on the relationship of the group member and group of the outer.

Figure 5-37

5.8.2.13 Register

The auto register interface is shown as below. See Figure 5-38.

This function allows the device to auto register to the proxy you specified. In this way, you can use the client-end to access the NVR and etc via the proxy. Here the proxy has a switch function. In the network service, device supports the server address of IPv4 or domain.

Please follow the steps listed below to use this function.

Please set proxy server address, port, and sub-device name at the device-end. Please enable the auto register function, the device can auto register to the proxy server.

REGISTER

☐ Enable

Server IP: 0.0.0.0

Port: 8000

Sub-device ID: 0

Save Refresh Default

Figure 5-38

5.8.2.14 Alarm Centre

The alarm center interface is shown as below. See Figure 5-39.

This interface is reserved for you to develop. System can upload alarm signal to the alarm center when local alarm occurs.

Before you use alarm center, please set server IP, port and etc. When an alarm occurs, system can send out data as the protocol defined, so the client-end can get the data.

ALARM CENTRE

☐ Enable

Protocol Type: ALARM CENTRE

Server IP: 10 . 1 . 0 . 2

Port: 1

Selfreport Time: Everyday at 08:00

Save Refresh Default

Figure 5-39

5.8.3 Event

5.8.3.1 Detect

5.8.3.1.1 Motion Detect

After analysis video, system can generate a video loss alarm when the detected moving signal reached the sensitivity you set here.

The motion detect interface is shown as in Figure 5-40.

Motion Detect

Video Loss

Camera Masking

☐ Enable

1

Period

Setup

Anti-dither

5

Second (0-600)

Region

Setup

☒ Record Channel

Setup

Delay

10

Second (10-300)

☐ Alarm Out

1

2

Latch

10

Second(1-300)

PTZ Activation

Setup

Tour

Setup

Snapshot

Setup

Show Message

☐ Send Email
 ☐ Alarm Upload
 ☐ Buzzer

Copy

Save

Refresh

Default

Figure 5-40

Setup

Wednesday

Copy

☒ 00 : 00 — 24 : 00
 ☐ 00 : 00 — 24 : 00
 ☐ 00 : 00 — 24 : 00
 ☐ 00 : 00 — 24 : 00
 ☐ 00 : 00 — 24 : 00
 ☐ 00 : 00 — 24 : 00

Save

Cancel

Figure 5-41

154




Figure 5-42




Figure 5-43




Figure 5-44




Figure 5-45

Please refer to the following sheet for detailed information.

Parameter	Function
Enable	You need to check the box to enable motion detection function. Please select a channel from the dropdown list.
Period	Motion detection function becomes activated in the specified periods. See Figure 5-41. There are six periods in one day. Please draw a circle to enable corresponding period. Click OK button, system goes back to motion detection interface, please click save button to exit.
Anti-dither	System only memorizes one event during the anti-dither period. The value ranges from 5s to 600s.
Sensitivity	There are six levels. The sixth level has the highest sensitivity.
Region	If you select motion detection type, you can click this button to set motion detection zone. The interface is shown as in Figure 5-42. Here you can set motion detection zone. There are four zones for you to set. Please select a zone first and then left drag the mouse to select a zone. The corresponding color zone displays different detection zone. You can click Fn button to switch between the arm mode and disarm mode. In arm mode, you can click the direction buttons to move the green rectangle to set the motion detection zone. After you completed the setup, please click ENTER button to exit current setup. Do remember click save button to save current setup. If you click ESC button to exit the region setup interface system will not save your zone setup.
Record channel	System auto activates motion detection channel(s) to record once an alarm occurs. Please note you need to set motion detect record period and go to Storage-> Schedule to set current channel as schedule record.
Delay	System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.
Alarm out	Enable alarm activation function. You need to select alarm output port so that system can activate corresponding alarm device when an alarm occurs.
Latch	System can delay the alarm output for specified time after an alarm ended. The value ranges from 1s to 300s.
Show message	System can pop up a message to alarm you in the local host screen if you enabled this function.

Parameter	Function
Buzzer	Check the box here to enable this function. The buzzer beeps when an alarm occurs.
Alarm upload	System can upload the alarm signal to the centre (Including alarm centre).
Message	When 3G network connection is OK, system can send out a message when motion detect occurs.
Send Email	If you enabled this function, System can send out an email to alert you when an alarm occurs.
Tour	You need to click setup button to select tour channel. System begins 1-window or multiple-window tour display among the channel(s) you set to record when an alarm occurs. See Figure 5-44.
PTZ Activation	Here you can set PTZ movement when alarm occurs. Such as go to preset X. See Figure 5-43.
Snapshot	Click setup button to select snapshot channel. See Figure 5-45.
Video Matrix	This function is for motion detect only. Check the box here to enable video matrix function. Right now system supports one-channel tour function. System takes “first come and first serve” principle to deal with the activated tour. System will process the new tour when a new alarm occurs after previous alarm ended. Otherwise it restores the previous output status before the alarm activation.

5.8.3.1.2 Video Loss

The video loss interface is shown as in Figure 5-46.

Please note video loss does not support anti-dither, sensitivity, region setup. For rest setups, please refer to chapter 5.8.3.1.1 motion detect for detailed information.

Figure 5-46

5.8.3.1.3 Tampering

The tampering interface is shown as in Figure 5-47.

After analysis video, system can generate a camera masking alarm when the detected moving signal reached the sensitivity you set here.

For detailed setups, please refer to chapter 5.8.3.1.1 motion detect for detailed information.

The screenshot shows the 'Camera Masking' configuration page. It has three tabs: 'Motion Detect', 'Video Loss', and 'Camera Masking' (which is active). The interface includes the following settings:

- Enable:** A checkbox that is checked, followed by a dropdown menu showing '1'.
- Period:** A button labeled 'Setup'.
- Record Channel:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Delay:** A text input field with '10' and a label 'Second (10-300)'.
- Alarm Out:** A checkbox that is checked, followed by two buttons labeled '1' and '2'.
- Latch:** A text input field with '10' and a label 'Second(1-300)'.
- PTZ Activation:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Tour:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Snapshot:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Show Message:** A checkbox that is checked, followed by three checkboxes: 'Send Email', 'Alarm Upload', and 'Buzzer'.

At the bottom, there are four buttons: 'Copy', 'Save', 'Refresh', and 'Default'.

Figure 5-47

5.8.3.2 Alarm

Before operation, please make sure you have properly connected alarm devices such as buzzer. The input mode includes local alarm and network alarm.

5.8.3.2.1 Alarm

The local alarm interface is shown as in Figure 5-48. It refers to alarm from the local device.

The screenshot shows the 'Local Alarm' configuration page. It has four tabs: 'Local' (which is active), 'Net Alarm', 'IPC External Alarm', and 'IPC Offline'. The interface includes the following settings:

- Enable:** A checkbox that is checked, followed by a dropdown menu showing '1'.
- Alarm Alias:** A text input field.
- Period:** A button labeled 'Setup'.
- Anti-dither:** A text input field with '5' and a label 'sec.(0-600)'.
- Type:** A dropdown menu showing 'Normal Open'.
- Record Channel:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Delay:** A text input field with '10' and a label 'sec. (10-300)'.
- Alarm Out:** A checkbox that is checked, followed by two buttons labeled '1' and '2'.
- Latch:** A text input field with '10' and a label 'sec.(1-300)'.
- PTZ Activation:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Tour:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Snapshot:** A checkbox that is checked, followed by a button labeled 'Setup'.
- Show Message:** A checkbox that is checked, followed by three checkboxes: 'Send Email', 'Alarm Upload', and 'Buzzer'.

At the bottom, there are four buttons: 'Copy', 'Save', 'Refresh', and 'Default'.

Figure 5-48

Setup

Wednesday ▼ Copy

☒ 00 : 00 — 24 : 00

☐ 00 : 00 — 24 : 00

☐ 00 : 00 — 24 : 00

☐ 00 : 00 — 24 : 00

☐ 00 : 00 — 24 : 00

☐ 00 : 00 — 24 : 00

Save Cancel

Figure 5-49

PTZ Activation

Channel 1 None ▼ 0

Channel 2 None ▼ 0

Channel 3 None ▼ 0

Channel 4 None ▼ 0

Channel 5 None ▼ 0

Channel 6 None ▼ 0

Channel 7 None ▼ 0

Channel 8 None ▼ 0

Save Cancel

Figure 5-50

Please refer to the following sheet for detailed information.

Parameter	Function
Enable	You need to check the box to enable this function. Please select a channel from the dropdown list.
Period	This function becomes activated in the specified periods. There are six periods in one day. Please draw a circle to enable corresponding period. Select date. If you do not select, current setup applies to today only. You can select all week column to apply to the whole week.

Parameter	Function
	Click OK button, system goes back to local alarm interface, please click save button to exit.
Anti-dither	System only memorizes one event during the anti-dither period. The value ranges from 5s to 600s.
Sensor type	There are two options: NO/NC.
Record channel	System auto activates motion detection channel(s) to record once an alarm occurs. Please note you need to set alarm record period and go to STORAGE-> SCHEDULE to set current channel as schedule record.
Delay	System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.
Alarm out	Enable alarm activation function. You need to select alarm output port so that system can activate corresponding alarm device when an alarm occurs.
Latch	System can delay the alarm output for specified time after an alarm ended. The value ranges from 1s to 300s.
Show message	System can pop up a message to alarm you in the local host screen if you enabled this function.
Buzzer	Check the box here to enable this function. The buzzer beeps when an alarm occurs.
Alarm upload	System can upload the alarm signal to the centre (Including alarm centre).
Send Email	If you enabled this function, System can send out an email to alert you when an alarm occurs.
Tour	You need to click setup button to select tour channel. System begins 1-window or multiple-window tour display among the channel(s) you set to record when an alarm occurs. See Figure 5-44.
PTZ Activation	Here you can set PTZ movement when alarm occurs. Such as go to preset X. See Figure 5-50.
Snapshot	Click setup button to select snapshot channel. See Figure 5-45.

5.8.3.2.2 Net Alarm

The network alarm interface is shown as in Figure 5-51.

Network alarm refers to the alarm signal from the network. System does not anti-dither and sensor type setup. For setup information, please refer to chapter 5.8.3.2.1.

Figure 5-51

5.8.3.2.3 IPC External Alarm

The IPC external alarm interface is shown as in Figure 5-52.

Network alarm refers to the alarm signal from the network. System does not anti-dither and sensor type setup. For setup information, please refer to chapter 5.8.3.2.1.

Figure 5-52

5.8.3.2.4 IPC Offline Alarm

The IPC offline alarm interface is shown as in Figure 5-53.

System can generate an alarm once the network camera is offline. For setup information, please refer to chapter 5.8.3.2.1.

Local	Net Alarm	IPC External Alarm	IPC Offline
<input checked="" type="checkbox"/> Enable <input type="text" value="1"/>			
<input type="checkbox"/> Record Channel <input type="button" value="Setup"/>			
Delay <input type="text" value="10"/> sec. (10-300)			
<input type="checkbox"/> Alarm Out <input type="text" value="1"/> <input type="text" value="2"/>			
Latch <input type="text" value="10"/> sec.(1-300)			
<input type="checkbox"/> PTZ Activation <input type="button" value="Setup"/>			
<input type="checkbox"/> Tour <input type="button" value="Setup"/>			
<input type="checkbox"/> Snapshot <input type="button" value="Setup"/>			
<input type="checkbox"/> Show Message <input type="checkbox"/> Send Email <input type="checkbox"/> Alarm Upload <input type="checkbox"/> Buzzer			
<input type="button" value="Copy"/> <input type="button" value="Save"/> <input type="button" value="Refresh"/> <input type="button" value="Default"/>			

Figure 5-53

5.8.3.3 Abnormality

It includes six types: No disk, disk error, disk no space, disconnect, IP conflict and MAC conflict. See Figure 5-54 through Figure 5-59.

No HDD	HDD Error	No Space	Disconnect	IP Conflict	MAC Conflict
<input checked="" type="checkbox"/> Enable					
<input type="checkbox"/> Alarm Out <input type="text" value="1"/> <input type="text" value="2"/>					
Latch <input type="text" value="10"/> sec.(1-300)					
<input type="checkbox"/> Show Message <input type="checkbox"/> Send Email <input type="checkbox"/> Alarm Upload <input type="checkbox"/> Buzzer					
<input type="button" value="Save"/> <input type="button" value="Refresh"/>					

Figure 5-54

No HDD	HDD Error	No Space	Disconnect	IP Conflict	MAC Conflict
<input checked="" type="checkbox"/> Enable					
<input type="checkbox"/> Alarm Out <input type="text" value="1"/> <input type="text" value="2"/>					
Latch <input type="text" value="10"/> sec.(1-300)					
<input type="checkbox"/> Show Message <input type="checkbox"/> Send Email <input type="checkbox"/> Alarm Upload <input type="checkbox"/> Buzzer					
<input type="button" value="Save"/> <input type="button" value="Refresh"/>					

Figure 5-55

No HDD	HDD Error	No Space	Disconnect	IP Conflict	MAC Conflict
<input checked="" type="checkbox"/> Enable	Less Than <input type="text" value="20"/> %				
<input type="checkbox"/> Alarm Out	<input type="text" value="1"/> <input type="text" value="2"/>				
Latch	<input type="text" value="10"/> sec.(1-300)				
<input type="checkbox"/> Show Message	<input type="checkbox"/> Send Email <input type="checkbox"/> Alarm Upload <input type="checkbox"/> Buzzer				
<input type="button" value="Save"/>		<input type="button" value="Refresh"/>			

Figure 5-56

No HDD	HDD Error	No Space	Disconnect	IP Conflict	MAC Conflict
<input checked="" type="checkbox"/> Enable					
<input type="checkbox"/> Alarm Out	<input type="text" value="1"/> <input type="text" value="2"/>				
Latch	<input type="text" value="10"/> sec.(1-300)				
<input type="checkbox"/> Show Message	<input type="checkbox"/> Send Email <input type="checkbox"/> Buzzer				
<input type="button" value="Save"/>		<input type="button" value="Refresh"/>			

Figure 5-57

No HDD	HDD Error	No Space	Disconnect	IP Conflict	MAC Conflict
<input checked="" type="checkbox"/> Enable					
<input type="checkbox"/> Alarm Out	<input type="text" value="1"/> <input type="text" value="2"/>				
Latch	<input type="text" value="10"/> sec.(1-300)				
<input type="checkbox"/> Show Message	<input type="checkbox"/> Send Email <input type="checkbox"/> Buzzer				
<input type="button" value="Save"/>		<input type="button" value="Refresh"/>			

Figure 5-58

No HDD	HDD Error	No Space	Disconnect	IP Conflict	MAC Conflict
<input checked="" type="checkbox"/> Enable					
<input type="checkbox"/> Alarm Out	<input type="text" value="1"/> <input type="text" value="2"/>				
Latch	<input type="text" value="10"/> sec.(1-300)				
<input type="checkbox"/> Show Message	<input type="checkbox"/> Send Email <input type="checkbox"/> Buzzer				
<input type="button" value="Save"/>		<input type="button" value="Refresh"/>			

Figure 5-59

Please refer to the following sheet for detailed information.

Parameter	Function
Event Type	The abnormal events include: No disk, disk error, disk no space, net disconnection, IP conflict and MAC conflict. You can set one or more items here. Less than: You can set the minimum percentage value here (For disk not space only). The device can alarm when capacity is not sufficient. You need to draw a circle to enable this function.
Enable	Check the box here to enable selected function.
Alarm Out	Please select corresponding alarm output channel when an alarm occurs. You need to check the box to enable this function.
Latch	The alarm output can delay for the specified time after an alarm stops. The value ranges from 1s to 300s.
Show message	System can pop up a message to alarm you in the local host screen if you enabled this function.
Alarm upload	System can upload the alarm signal to the centre (Including alarm centre).
Send Email	If you enabled this function, System can send out an email to alert you when an alarm occurs.
Buzzer	Check the box here to enable this function. The buzzer beeps when an alarm occurs.

5.8.4 Storage

5.8.4.1 Schedule

In this interfaces, you can add or remove the schedule record setup. See Figure 5-60.

There are four record modes: general (auto), motion detect, alarm and MD&Alarm. There are six periods in one day.

You can view the current time period setup from the color bar.

- Green color stands for the general record/snapshot.
- Yellow color stands for the motion detect record/snapshot..
- Red color stands for the alarm record/snapshot.
- Blue color stands for MD&Alarm record/snapshot.

Record Snapshot

Channel Pre-record Second (0~30) ☐ Redundancy

☐ ANR Second

	0	2	4	6	8	10	12	14	16	18	20	22	24	
Sunday														Setup
Monday														Setup
Tuesday														Setup
Wednesday														Setup
Thursday														Setup
Friday														Setup
Saturday														Setup
Holiday														Setup

Copy Save Refresh Default

Figure 5-60

Setup ✕

Time Period 1	<input type="text" value="00 : 00"/>	<input type="text" value="24 : 00"/>	<input checked="" type="checkbox"/> Regular	<input type="checkbox"/> Motion	<input type="checkbox"/> Alarm	<input type="checkbox"/> MD&Alarm
Time Period 2	<input type="text" value="00 : 00"/>	<input type="text" value="24 : 00"/>	<input type="checkbox"/> Regular	<input type="checkbox"/> Motion	<input type="checkbox"/> Alarm	<input type="checkbox"/> MD&Alarm
Time Period 3	<input type="text" value="00 : 00"/>	<input type="text" value="24 : 00"/>	<input type="checkbox"/> Regular	<input type="checkbox"/> Motion	<input type="checkbox"/> Alarm	<input type="checkbox"/> MD&Alarm
Time Period 4	<input type="text" value="00 : 00"/>	<input type="text" value="24 : 00"/>	<input type="checkbox"/> Regular	<input type="checkbox"/> Motion	<input type="checkbox"/> Alarm	<input type="checkbox"/> MD&Alarm
Time Period 5	<input type="text" value="00 : 00"/>	<input type="text" value="24 : 00"/>	<input type="checkbox"/> Regular	<input type="checkbox"/> Motion	<input type="checkbox"/> Alarm	<input type="checkbox"/> MD&Alarm
Time Period 6	<input type="text" value="00 : 00"/>	<input type="text" value="24 : 00"/>	<input type="checkbox"/> Regular	<input type="checkbox"/> Motion	<input type="checkbox"/> Alarm	<input type="checkbox"/> MD&Alarm

☐ All ☒ Sunday ☐ Monday ☐ Tuesday ☐ Wednesday ☐ Thursday ☐ Friday ☐ Saturday

Save Cancel

Figure 5-61




Figure 5-62

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Please select a channel from the dropdown list.
Pre-record	Please input pre-record time here. The value ranges from 0 to 30.
Redundancy	Check the box here to enable redundancy function. Please note this function is null if there is only one HDD.
Snapshot	Check the box here to enable snapshot function.
Holiday	Check the box here to enable holiday function.
Setup	Click the Setup button, you can set record period. See Figure 5-61. There are six periods in one day. If you do not check the date at the bottom of the interface, current setup is for today only. Please click Save button and then exit.
Copy	Copy function allows you to copy one channel setup to another. After setting in channel, click Copy button, you can go to interface Figure 5-62. You can see current channel name is grey such as channel 1. Now you can select the channel you want to paste such as channel 5/6/7. If you want to save current setup of channel 1 to all channels, you can click the first box "ALL". Click the OK button to save current copy setup. Click the OK button in the Encode interface, the copy function succeeded.

5.8.4.2 STORAGE

5.8.4.2.1 Local Storage

The local interface is shown as in Figure 5-63. Here you can see HDD information. You can also operate the read-only, read-write, redundancy (if there are more than on HDD) and format operation.




Figure 5-63

5.8.4.2.2 HDD

The HDD interface is to set HDD group. See Figure 5-64.



Figure 5-64

5.8.4.3 Record Control

The interface is shown as in Figure 5-65.




Figure 5-65

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Here you can view channel number. The number displayed here is the max channel amount of your

	device.
Status	There are three statuses: Auto, Manual, off.
Auto	System enables auto record function as you set in record schedule setup (general, motion detect and alarm).
Manual	It has the highest priority. Enable corresponding channel to record no matter what period applied in the record setup.
Off	Stop current channel record no matter what period applied in the record setup.
Start all/ stop all	Check the corresponding All button, you can enable or disable all channels record.

5.8.4.4 HDD MANAGER

5.8.4.4.1 Main Stream

The main stream interface is shown as in Figure 5-66. Here you can set corresponding HDD group to save main stream.

Channel	HDD Group	Channel	HDD Group	Channel	HDD Group	Channel	HDD Group
Channel 1	1	Channel 2	1	Channel 3	1	Channel 4	1
Channel 5	1	Channel 6	1	Channel 7	1	Channel 8	1

Figure 5-66

5.8.4.4.2 Sub Stream

The extra stream interface is shown as in Figure 5-67.

Here you can set corresponding HDD group to save sub stream.

Channel	HDD Group	Channel	HDD Group	Channel	HDD Group	Channel	HDD Group
Channel 1	1	Channel 2	1	Channel 3	1	Channel 4	1
Channel 5	1	Channel 6	1	Channel 7	1	Channel 8	1

Figure 5-67

5.8.4.4.3 Snapshot

The image storage interface is shown as in Figure 5-68. Here you can set corresponding HDD group to save snapshot picture.

Channel	HDD Group	Channel	HDD Group	Channel	HDD Group	Channel	HDD Group
Channel 1	1	Channel 2	1	Channel 3	1	Channel 4	1
Channel 5	1	Channel 6	1	Channel 7	1	Channel 8	1

Figure 5-68

5.8.5 Setting

5.8.5.1 General

The general interface includes general, date/time and holiday setup.

5.8.5.1.1 General

The general interface is shown as in Figure 5-69.

Device Name	NVR
Device No.	8
Language	ENGLISH
Video Standard	PAL
HDD Full	OverWrite
Pack Duration	60 Minute

Figure 5-69

Please refer to the following sheet for detailed information.

Parameter	Function
Device Name	It is to set device name.
Device No.	It is device channel number.
Language	You can select the language from the dropdown list. Please note the device needs to reboot to get the modification activated.
Video Standard	This is to display video standard such as PAL or NTSC.

HDD full	Here is for you to select working mode when hard disk is full. There are two options: stop recording or overwrite. If current working HDD is overwritten or the current HDD is full while the next HDD is no empty, then system stops recording, If the current HDD is full and then next HDD is not empty, then system overwrites the previous files.
Pack duration	Here is for you to specify record duration. The value ranges from 1 to 120 minutes. Default value is 60 minutes.

5.8.5.1.2 Date and time

The date and time interface is shown as in Figure 5-70

Figure 5-70

Please refer to the following sheet for detailed information.

Parameter	Function
Date format	Here you can select date format from the dropdown list.
Time Format	There are two options: 24-H and 12-H.
Time zone	The time zone of the device.
System time	It is to set system time. It becomes valid after you set.
Sync PC	You can click this button to save the system time as your PC current time.
DST	Here you can set day night save time begin time and end time. You can set according to the date format or according to the week format.
NTP	You can check the box to enable NTP function.
Server	You can set the time server address.
Port	It is to set the time server port.
Interval	It is to set the sync periods between the device and the time server.

5.8.5.1.3 Holiday Setup

Holiday setup interface is shown as in Figure 5-71.

Here you can click Add New Holidays box to add a new holiday and then click Save button to save.

The screenshot displays the 'Holiday' management interface. At the top, there are tabs for 'GENERAL', 'Date&Time', and 'Holiday'. An 'Add New Holidays' button is located in the top right corner. Below it is a table with the following data:

No.	Status	Holiday Name	Date	Period	Repeat Mode	Edit	Delete
1	Enable	National	2014.7.4	1 day(s)	Always		

At the bottom of the interface, there are three buttons: 'Save', 'Refresh', and 'Default'.

Figure 5-71

5.8.5.2 Account

Note:

- For the character in the following user name or the user group name, system max supports 6-digits. The space in the front or at the end of the string is null. The valid string includes: character, number, and underline.
- The user amount default setup is 64 and the group amount default setup is 20. You can set the corresponding group and then set the rights for the respective user in the specified groups.
- User management adopts group/user modes. The user name and the group name shall be unique. One user shall be included in only one group.

5.8.5.2.1 User name

In this interface you can add/remove user and modify user name. See Figure 5-72.

The screenshot displays the 'Account' management interface. At the top, there are tabs for 'User' and 'Group'. Below it is a table with the following data:

SN	Username	Group Name	Memo	Modify	Delete
1	888888	admin	888888 admin 's account		
2	666666	user	666666 user's account		
3	admin	admin	admin 's account		
4	default	user	default account		

At the bottom left of the interface, there is an 'Add User' button.

Figure 5-72

Add user: It is to add a name to group and set the user rights. See Figure 5-73.

There is one default user:ADMIN. The user has administrator right.

Here you can input the user name and password and then select one group for current user.

Please note the user rights shall not exceed the group right setup.

For convenient setup, please make sure the general user has the lower rights setup than the admin.

Add User

Username

Reuseable ☐

Password

Confirm Password

Group

Memo

Authority

System Playback Real-time Monitor

☒ All

☒ Account ☒ System ☒ Disconnect ☒ Default&Update

☒ PTZ Control ☒ System Info ☒ Manual Control ☒ File Backup

☒ Storage ☒ Event ☒ Network ☒ Remote Device

☒ Clear Log ☒ Shut Down

Save Cancel

Figure 5-73


Modify user

It is to modify the user property, belonging group, password and rights. See Figure 5-74.

Modify password

It is to modify the user password. You need to input the old password and then input the new password twice to confirm the new setup. Please click the OK button to save.

Please note, the password ranges from 1-digit to 6-digit. It shall include the number only. For the user of the account rights, he can modify the password of other users.



Modify User

Username: 666666

Username: 666666

Reuseable: ☒

Group: user

Memo: 666666 user's account

☐ Modify Password

Authority

System | Playback | Real-time Monitor

☒ All

☐ Account ☐ System ☐ Disconnect ☐ Default&Update

☒ PTZ Control ☒ System Info ☒ Manual Control ☒ File Backup

☐ Storage ☐ Event ☐ Network ☐ Remote Device


☐ Clear Log ☐ Shut Down

Save Cancel

Figure 5-74

5.8.5.2.2 Group

The group management interface can add/remove group, modify group password and etc. The interface is shown as in Figure 5-75.



Account

User | **Group**

SN	Group Name	Memo	Modify	Delete
1	admin	administrator group		
2	user	user group		

Add Group

Figure 5-75

Add group: It is to add group and set its corresponding rights. See Figure 5-76.

Please input the group name and then check the box to select the corresponding rights. It includes: shutdown/reboot device, live view, record control, PTZ control and etc.

Add Group

Group Name

Memo

Authority

System Playback Real-time Monitor

☒ All

<input checked="" type="checkbox"/> Account	<input checked="" type="checkbox"/> System	<input checked="" type="checkbox"/> Disconnect	<input checked="" type="checkbox"/> Default&Update
<input checked="" type="checkbox"/> PTZ Control	<input checked="" type="checkbox"/> System Info	<input checked="" type="checkbox"/> Manual Control	<input checked="" type="checkbox"/> File Backup
<input checked="" type="checkbox"/> Storage	<input checked="" type="checkbox"/> Event	<input checked="" type="checkbox"/> Network	<input checked="" type="checkbox"/> Remote Device
<input checked="" type="checkbox"/> Clear Log	<input checked="" type="checkbox"/> Shut Down		

Save Cancel

Figure 5-76

Modify group

Click the modify group button, you can see an interface is shown as in Figure 5-77.

Here you can modify group information such as remarks and rights.

Modify Group

Group Name:

Group Name:

Memo:

Authority:

System | Playback | Real-time Monitor

- ☒ All
- ☒ Account
- ☒ PTZ Control
- ☒ Storage
- ☒ Clear Log
- ☒ System
- ☒ System Info
- ☒ Event
- ☒ Shut Down
- ☒ Disconnect
- ☒ Manual Control
- ☒ Network
- ☒ Default&Update
- ☒ File Backup
- ☒ Remote Device

Figure 5-77

5.8.5.3 Display

Display interface includes GUI, TV adjust, Tour and zero-channel encoding.

5.8.5.3.1 Display

Here you can set background color and transparency level. See Figure 5-78.

Display | Tour

Resolution:

Transparency: ☒ 0%

Time Display: ☐

Channel Display: ☒

Image Enhance: ☒

Auto Logout: Minute(0-60)

Startup Wizard: ☒

Navigation Bar: ☒

Original Scale: ☐

Figure 5-78

Please refer to the following sheet for detailed information.

Parameter	Function
Resolution	There are four options: 1920×1080,1280×1024(default),1280×720,1024×768. Please note the system needs to reboot to activate current setup.
Transparency	Here is for you to adjust transparency. The value ranges from 128 to 255.
Time title/channel title	Check the box here, you can view system time and channel number on the monitor video.
Image enhance	Check the box; you can optimize the margin of the preview video.

5.8.5.3.2 Tour

The tour interface is shown as in Figure 5-79. Here you can set tour interval, split mode, motion detect tour and alarm tour mode.




Figure 5-79

Please refer to the following sheet for detailed information.

Parameter	Function
Enable tour	Check the box here to enable tour function.
Interval	Here is for you to adjust transparency. The value ranges from 5 to 120s. The default setup is 5s.
Split	Here you can set window mode and channel group. System can support 1/4/8/9/16/25/36-window according to device channel amount.
Motion tour/Alarm tour	Here you can set motion detect tour/alarm tour window mode. System supports 1/8-window now.

5.8.5.4 Alarm Out

The alarm output interface is shown as below. See Figure 5-80

Here you can set alarm output mode: auto/manual/stop.




Figure 5-80

5.8.5.5 Default

The default setup interface is shown as in Figure 5-81.

Here you can select Network/Event/STORAGE/System Config/Remote Device. Or you can check the All box to select all items.




Figure 5-81

5.8.5.6 Import/Export

The interface is shown as in Figure 5-82. This interface is for you to export or import the configuration files.




Figure 5-82

Please refer to the following sheet for detailed information.

Parameter	Function
Browse	Click to select import file.

Parameter	Function
Config Import	It is to import the local setup files to the system.
Config Export	It is to export the corresponding WEB setup to your local PC.

5.8.5.7 Auto maintain

The auto maintain interface is shown as in Figure 5-83.

Here you can select auto reboot and auto delete old files interval from the dropdown list.

If you want to use the auto delete old files function, you need to set the file period.

Click Manual reboot button, you can restart device manually.

Figure 5-83

5.8.5.8 Upgrade

The upgrade interface is shown as in Figure 5-84.

Please select the upgrade file and then click the update button to begin update. Please note the file name shall be as *.bin. During the upgrade process, do not unplug the power cable, network cable, or shutdown the device.

Important

Improper upgrade program may result in device malfunction! Please make sure the operation is operated under the supervision of the professional engineer!

Figure 5-84

5.8.5.9 RS232

The RS232 interface is shown as in Figure 5-85.

RS232

Function: Console

Baud Rate: 115200

Data Bit: 8

Stop Bit: 1

Parity: None

Save Refresh Default

Figure 5-85

Please refer to the following sheet for detailed information.

Parameter	Function
Function	Select the corresponding dome protocol. Default setup is console.
Baud Rate	Select the baud rate. Default setup is 115200.
Data Bit	The value ranges from 5 to 8. Default setup is 8.
Stop bit	There are two options: 1/2. Default setup is 1.
Parity	There are five options: none/odd/even/space/mark. Default setup is none.

5.8.5.10 PAN/TILT/ZOOM

The PTZ interface is shown as in Figure 5-86 (Local) and Figure 5-87 (Remote).

Before setup, please check the following connections are right:

- PTZ and decoder connection is right. Decoder address setup is right.
- Decoder A (B) line connects with NVR A (B) line.

Click Save button after you complete setup, you can go back to the monitor interface to control speed dome.

PAN/TILT/ZOOM

Channel: 2

PTZ Type: Local

Protocol: NONE

Address: 1

Baud Rate: 9600

Data Bit: 8

Stop Bit: 1

Parity: None

Copy Save Refresh Default

Figure 5-86

PAN/TILT/ZOOM

Channel: 1

PTZ Type: Remote

Copy Save Refresh Default

Figure 5-87

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Select speed dome connected channel.
PTZ Type	There are two options: local/remote. Please select remote type if you are connecting to the network PTZ.
Protocol	Select the corresponding dome protocol such as PELCOD.
Address	Set corresponding dome address. Default value is 1. Please note your setup here shall comply with your dome address; otherwise you cannot control the speed dome.
Baud Rate	Select the dome baud rate. Default setup is 9600.
Data Bit	Default setup is 8. Please set according to the speed dome dial switch setup.
Stop bit	Default setup is 1. Please set according to the speed dome dial switch setup.
Parity	Default setup is none. Please set according to the speed dome dial switch setup.

5.9 Information

5.9.1 Version

The version interface is shown as in Figure 5-88.

Here you can view record channel, alarm input/output information, software version, release date and etc.

Please note the following information is for reference only.

Version

Record Channel: 8

Alarm In: 4

Alarm Out: 2

SN: YPA4AQ022W00005

Web: 3.1.0.4

System Version: 3.200.TY00.0

Build Date: 2014-06-05

Figure 5-88

5.9.2 Log

Here you can view system log. See Figure 5-89.

The screenshot shows a web interface titled "Log". At the top, there are input fields for "Begin Time" (2014 - 06 - 10 00 : 00 : 00) and "End Time" (2014 - 06 - 11 00 : 00 : 00). Below these is a "Type" dropdown menu set to "All" and a "Search" button. To the right of the search button, it says "Matched 1024 logs Log Time 2014-06-10 13:03:27 -- 2014-06-10 15:21:08".

No.	Time	Event
1	2014-06-10 13:03:27	REMOTE INFO
2	2014-06-10 13:03:27	REMOTE INFO
3	2014-06-10 13:04:07	REMOTE INFO
4	2014-06-10 13:04:07	REMOTE INFO
5	2014-06-10 13:04:07	REMOTE INFO
6	2014-06-10 13:04:07	REMOTE INFO
7	2014-06-10 13:04:27	REMOTE INFO
8	2014-06-10 13:04:27	REMOTE INFO
9	2014-06-10 13:04:27	REMOTE INFO
10	2014-06-10 13:04:27	REMOTE INFO

Below the table is a section titled "System Log Info" which is currently empty. At the bottom of the interface, there are two buttons: "Backup" on the left and "Clear" on the right. In the bottom right corner, there are navigation controls showing "1 / 11" and a "Go To" button with the number "1" selected.

Figure 5-89

Please refer to the following sheet for log parameter information.

Parameter	Function
Type	Log types include: system operation, configuration operation, data operation, event operation, record operation, user management and log clear.
Begin time	Set the start time of the requested log.
End time	Set the end time of the requested log.
Search	You can select log type from the drop down list and then click search button to view the list. You can click the stop button to terminate current search operation.
Detailed information	You can select one item to view the detailed information.
Clear	You can click this button to delete all displayed log files. Please note system does not support clear by type.
Backup	You can click this button to backup log files to current PC.

5.9.3 Online User

The online user interface is shown as in Figure 5-90.

Then please click File list button, you can see the corresponding files in the list. See Figure 5-92.




Figure 5-92

Select a file you want to play and then click Play button, system can begin playback. You can select to playback in full-screen. Please note for one channel, system cannot playback and download at the same time. You can use the playback control bar to implement various operations such as play, pause, stop, slow play, fast play and etc. See Figure 5-93.




Figure 5-93

Select the file(s) you want to download and then click download button, you can see an interface shown as in Figure 5-94. The Download button becomes Stop button and there is a process bar for your reference. Please go to your default file saved path to view the files.




Figure 5-94

Load more

Click More button in Figure 5-94, you can see an interface shown as in Figure 5-95. It is for you to search record or picture. You can select record channel, record type and record time to download.




Figure 5-95

Watermark

Watermark interface is shown as in Figure 5-96. Please select a file and then click Verify button to see the file has been tampered with or not




Figure 5-96

5.11 Alarm

Click alarm function, you can see an interface is shown as Figure 5-97.

Here you can set device alarm type and alarm sound setup (Please make sure you have enabled audio function of corresponding alarm events.).




Figure 5-97


Please refer to the following sheet for detailed information.

Type	Parameter	Function
Alarm Type	Video loss	System alarms when video loss occurs.
	Motion detection	System alarms when motion detection alarm occurs.
	Tampering	System alarms when camera is viciously masking.
	HDD full	System alarms when disk is full.
	HDD error	System alarms when disk error occurs.
	External alarm	Alarm input device sends out alarm.
	IPC external alarm	It refers to the on-off signal from the network camera. It can activate the NVR local activation operation.
	IPC offline	System can generate an alarm when the network camera and the NVR are disconnected.
Operation	Prompt	Check the box here, system can automatically pops up an alarm icon on the Alarm button in the main interface when there is an alarm.
Alarm Sound	Play alarm sound	System sends out alarm sound when an alarm occurs. You can specify as you wish.
	Sound path	Here you can specify alarm sound file.

5.12 Log out

Click log out button, system goes back to log in interface. See Figure 5-98.

You need to input user name and password to login again.



LOG IN

Username: admin

Password:

☒ LAN ☐ WAN

Login Cancel

Figure 5-98

5.13 Un-install Web Control

You can use web un-install tool “uninstall web.bat” to un-install web control.

Please note, before you un-installation, please close all web pages, otherwise the un-installation might result in error.

6 Glossary

- **DHCP:** DHCP (Dynamic Host Configuration Protocol) is a network protocol. It is one of the TCP/IP protocol cluster. It is principally used to assign temporary IP addresses to computers on a network.
- **DDNS:** DDNS (Dynamic Domain Name Server) is a service that maps Internet domain names to IP addresses. This service is useful to anyone who wants to operate a server (web server, mail server, ftp server and etc) connected to the internet with a dynamic IP or to someone who wants to connect to an office computer or server from a remote location with software.
- **eSATA:** eSATA(External Serial ATA) is an interface that provides fast data transfer for external storage devices. It is the extension specifications of a SATA interface.
- **GPS:** GPS (Global Positioning System) is a satellite system, protected by the US military, safely orbiting thousands of kilometers above the earth.
- **PPPoE: PPPoE** (Point to Point Protocol over Ethernet) is a specification for connecting multiple computer users on an Ethernet local area network to a remote site. Now the popular mode is ADSL and it adopts PPPoE protocol.
- **WIFI:** Wi-Fi is the name of a popular wireless networking technology that uses radio waves to provide wireless high-speed Internet and network connections. The standard is for wireless local area networks (WLANs). It is like a common language that all the devices use to communicate to each other. It is actually IEEE802.11, a family of standard The IEEE (Institute of Electrical and Electronics Engineers Inc.)
- **3G:** 3G is the wireless network standard. It is called 3G because it is the third generation of cellular telecom standards. 3G is a faster network for phone and data transmission and speed is over several hundreds kbps. Now there are four standards: CDMA2000, WCDMA, TD-SCDMA and WiMAX.
- **Dual-stream:** The dual-stream technology adopts high-rate bit stream for local HD storage such as QCIF/CIF/2CIF/DCIF/4CIF encode and one low-rate bit stream for network transmission such as QCIF/CIF encode. It can balance the local storage and remote network transmission. The dual-stream can meet the difference band width requirements of the local transmission and the remote transmission. In this way, the local transmission using high-bit stream can achieve HD storage and the network transmission adopting low bit stream suitable for the fluency requirements of the 3G network such as WCDMA, EVDO, TD-SCDMA..
- **On-off value:** It is the non-consecutive signal sampling and output. It includes remote sampling and remote output. It has two statuses: 1/0.

7 Appendix A HDD Capacity Calculation

Calculate total capacity needed by each device according to video recording (video recording type and video file storage time).

Step 1: According to Formula (1) to calculate storage capacity q_i that is the capacity of each channel needed for each hour, unit Mbyte.

$$q_i = d_i \div 8 \times 3600 \div 1024 \quad (1)$$

In the formula: d_i means the bit rate, unit Kbit/s

Step 2: After video time requirement is confirmed, according to Formula (2) to calculate the storage capacity m_i , which is storage of each channel needed unit Mbyte.

$$m_i = q_i \times h_i \times D_i \quad (2)$$

In the formula:

h_i means the recording time for each day (hour)

D_i means number of days for which the video shall be kept

Step 3: According to Formula (3) to calculate total capacity (accumulation) q_T that is needed for all channels in the device during **scheduled video recording**.

$$q_T = \sum_{i=1}^c m_i \quad (3)$$

In the formula: c means total number of channels in one device

Step 4: According to Formula (4) to calculate total capacity (accumulation) q_T that is needed for all channels in device during **alarm video recording (including motion detection)**.

$$q_T = \sum_{i=1}^c m_i \times a\% \quad (4)$$

In the formula: $a\%$ means alarm occurrence rate